



USER MANUAL USA 2024-WAT-EU



For Serial Numbers:
TM805 XX X XXX



www.itape.com
800-474-8273

intertape
polymer
group®



Table of Contents

Chapter	Title	Page
1	GENERAL INFORMATION	1-1
1.1	Revision Control.....	1-1
1.2	Technical Support.....	1-1
1.3	Replacement Parts	1-1
1.4	Field Service Assistance.....	1-2
1.5	Warranty	1-2
1.6	Description of USA2024-WAT-EU Case Sealer	1-3
1.7	Optional Equipment	1-4
2	IMPORTANT SAFEGUARDS	2-1
2.1	Safety Labels	2-1
2.2	Safety Label Placement.....	2-2
2.3	Safety Label Descriptions	2-3
2.4	Explanation of Signal Word Consequences	2-6
2.5	Operator Skill Level Descriptions.....	2-7
2.5.1	Skill “A” Machine Operator	2-7
2.5.2	Skill “B” Mechanical Maintenance Technician.....	2-7
2.5.3	Skill “C” Electrical Maintenance Technician	2-7
2.5.4	Skill “D” Manufacturer’s Technician.....	2-7
3	SPECIFICATIONS	3-1
3.1	Machine Dimensions	3-1
3.2	Machine Components.....	3-2
3.3	Machine Operating Conditions	3-3
3.3.1	Power Requirements	3-3
3.3.2	Operating Speed	3-3
3.3.3	Tape Specifications	3-3
3.3.4	Carton Specifications.....	3-3
3.3.5	Case Processing Stability.....	3-4
4	SET-UP PROCEDURES	4-1
4.1	Receiving and Handling.....	4-1
4.2	Caster Installation (If Purchased)	4-2
4.3	Machine Height Adjustment.....	4-3
4.4	Installation of Interpack Brand In-Feed Roller Tables (If Purchased)	4-4
4.5	Installation of External In-Feed and Exit Conveyors.....	4-6

Chapter	Title	Page
4.6	Connecting Utilities	4-7
4.6.1	Electrical Utilities	4-7
4.6.2	Pneumatic Utilities	4-8
4.7	Operator Control Box	4-9
4.8	Operator Control Box Relocation	4-10
4.9	Top Tape Head Loading/Threading	4-11
4.10	Bottom Tape Head Loading/Threading	4-13
4.11	Adding Water to the System	4-15
5	OPERATING INSTRUCTIONS	5-1
5.1	Introduction to Operating Instructions	5-1
5.2	Case Size Set-Up Functions	5-2
5.3	Initial Condition	5-3
5.4	Preparing Case to be Processed	5-3
5.4.1	Flap Folding	5-3
5.4.2	Overfills and Voids	5-4
5.5	Case Height Adjustment	5-4
5.6	Case Width Adjustment	5-5
5.7	Top Squeezer Adjustment	5-5
5.8	Control Box	5-6
5.8.1	Auto Mode	5-6
5.8.2	Manual Mode	5-7
5.8.3	Clear Mode (Clear Jam)	5-7
6	TROUBLESHOOTING	6-1
7	PREVENTIVE MAINTENANCE	7-1
7.1	Machine Preventive Maintenance	7-1
7.2	Cleaning the Machine	7-2
7.2.1	Side Belt Drive Base	7-2
7.2.2	Column Shaft	7-2
7.2.3	Connecting Chain for Centering Assembly	7-2
7.3	Changing the Air Regulator Filter	7-3
7.4	Lubricating the Machine	7-4
7.4.1	Column Shaft	7-4
7.4.2	Acme Drive Base Shafts	7-4
7.4.3	Centering Chain	7-4

Chapter	Title	Page
7.5	Removing the Top Tape Head.....	7-5
7.6	Removing the Bottom Tape Head	7-6
7.7	Cleaning the Cutter Blade (Top Tape Head).....	7-7
7.8	Cleaning the Cutter Blade (Bottom Tape Head).....	7-8
7.9	Cutter Blade Maintenance	7-9
7.10	Cutter Blade Replacement.....	7-10
8	MACHINE MAINTENANCE & ADJUSTMENT	8-1
8.1	Drive Belt Replacement	8-1
8.2	Drive Belt Adjustment	8-2
9	ILLUSTRATED PARTS LIST	9-1

List of Figures

Figure	Name	Page
Figure 1-1	USA2024-WAT-EU Case Sealer	1-3
Figure 1-2	Optional Equipment	1-4
Figure 2-1	Safety Label Placement	2-2
Figure 3-1	Machine Dimensions	3-1
Figure 3-2	Machine Components	3-2
Figure 4-1	Receiving and Handling	4-1
Figure 4-2	Caster Installation	4-2
Figure 4-3	Adjustment of Machine Height	4-3
Figure 4-4	Case Direction	4-4
Figure 4-5	Carriage Bolt Installation	4-4
Figure 4-6	Roller Table to Machine Base Installation	4-5
Figure 4-7	Remaining Carriage Bolt Installation	4-5
Figure 4-8	Installing In-Feed and Exit Conveyors	4-6
Figure 4-9	Electrical Utilities	4-7
Figure 4-10	Main Air Regulator	4-8
Figure 4-11	Operator Control Box	4-9
Figure 4-12	Control Box Relocation	4-10
Figure 4-13	Top Tape Threading Diagram	4-11
Figure 4-14	Control Box – Top Threading	4-12
Figure 4-15	Top Tape Head Loading/Threading	4-12
Figure 4-16	Bottom Tape Threading Diagram	4-13
Figure 4-17	Control Box – Bottom Threading	4-14
Figure 4-18	Mandrel Slide Handle	4-14
Figure 4-19	Bottom Tape Head Loading/Threading	4-14
Figure 4-20	Adding Water to the System	4-15

Figure	Name	Page
Figure 5-1	E-stop Locations	5-1
Figure 5-2	Case Size Set-Up.....	5-2
Figure 5-3	Raise Upper Head.....	5-3
Figure 5-4	Open Side Drives	5-3
Figure 5-5	Open Top Squeezers.....	5-3
Figure 5-6	Fold Minor Flaps	5-3
Figure 5-7	Fold Major Flaps	5-3
Figure 5-8	Overfill	5-4
Figure 5-9	Void Fill.....	5-4
Figure 5-10	Insert Case	5-4
Figure 5-11	Adjust Upper Head.....	5-4
Figure 5-12	Case Width Adjustment.....	5-5
Figure 5-13	Top Squeezer Adjustment	5-5
Figure 5-14	Control Box	5-7
Figure 7-1	Machine Preventive Maintenance Chart.....	7-1
Figure 7-2	Cleaning the Machine	7-2
Figure 7-3	Remove Guard	7-3
Figure 7-4	Remove Reservoir	7-3
Figure 7-5	Remove Filter.....	7-3
Figure 7-6	Lubricating the Machine.....	7-4
Figure 7-7	Quick-disconnect.....	7-5
Figure 7-8	Electrical Disconnect.....	7-5
Figure 7-9	Quick-disconnect.....	7-5
Figure 7-10	Remove Water Pot.....	7-5
Figure 7-11	Pull Hold-down Plate.....	7-5
Figure 7-12	Remove Tape Head Box.....	7-5
Figure 7-13	Remove Side Covers	7-6
Figure 7-14	Electrical Disconnect.....	7-6

Figure	Name	Page
Figure 7-15	Quick-disconnect.....	7-6
Figure 7-16	Remove Water Pot.....	7-6
Figure 7-17	Quick-disconnect.....	7-6
Figure 7-18	Lift Tape Head.....	7-6
Figure 7-19	Remove Top Cover.....	7-7
Figure 7-20	Remove Tape Shoe and Water Pot.....	7-7
Figure 7-21	Clean Striker Plate.....	7-7
Figure 7-22	Remove Tape Shoe.....	7-8
Figure 7-23	Remove Water Pot.....	7-8
Figure 7-24	Clean Striker Plate.....	7-8
Figure 7-25	Cutter Blade Maintenance.....	7-9
Figure 7-26	Striker Plate and Cutting Blade.....	7-10
Figure 7-27	Striker Plate.....	7-10

Chapter 1 **GENERAL INFORMATION**

1.1 REVISION CONTROL

REV01 Second Release

1.2 TECHNICAL SUPPORT

This is the Interpack Model AUTO H2O Uniform Semi-Automatic 2024-WAT-EU Side-Belt Case Sealer (USA2024-WAT-EU Case Sealer) you ordered. It has been set up and tested in our factory with Intertape manufactured water activated tapes. If any problems occur when setting up or operating this equipment, please contact the authorized distributor from where you purchased this item.

If contact with the authorized distributor is not possible, Interpack Technical Support is available. Should the need to contact Interpack Technical Support arise, please have the Case Sealer model number and serial number on hand. This information can be found on the nameplate of the side panel of the machine. Interpack Technical Support is available during normal business hours (Eastern Time).

- **PHONE: 800-474-8273, Option 3**

If you have a technical question that does not require an immediate response, you may contact Interpack by fax.

- **FAX: 800-462-1293**

Technical support may also be contacted via email at the address below:

- **EMAIL: Machsupp@itape.com**

1.3 REPLACEMENT PARTS

Order parts by item number, part description, and quantity required. Replacement parts are available from your authorized Interpack distributor exclusively.

Should you require assistance selecting the correct part, you may call:

Intertape Polymer Group
Interpack Machinery

Tel: 1-800-474-8273, Option 3
Fax: 1-800-462-1293

MODEL: _____

SERIAL NUMBER: _____

DISTRIBUTOR PURCHASED FROM: _____

DATE OF PURCHASE: _____

1.4 FIELD SERVICE ASSISTANCE

This machine is designed to provide years of trouble-free operation. If any problems arise with this machine during the normal course of operation, your properly trained and qualified internal service personnel should be able to repair any issues after consulting Chapter 6, [Troubleshooting](#).

Service support is available from your authorized Interpack distributor at additional cost if the problem cannot be remedied after consulting the Troubleshooting chapter of this manual.

1.5 WARRANTY

EQUIPMENT WARRANTY AND LIMITED REMEDY: The following warranty is made in lieu of all other warranties, express or implied, including but not limited to the implied warranty of merchantability, the implied warranty of fitness for a particular purpose, and any implied warranty arising out of a course of dealing, a custom or usage of trade:

Intertape sells its Interpack Tape Heads, Case Tapers, and Case Erectors with the following warranties:

1. The HSD® 2000 Tape Heads' knife blades, springs and wipe down rollers will be free from all defects for a period of ninety (90) days.
2. All other HSD® 2000 Tape Head parts will be free from all defects for one (1) year after delivery.
3. Water Activated Tape Heads' blades will be free from defects for ninety (90) days after delivery.
4. Drive Belts will be free from defects for ninety (90) days after delivery.
5. The Gear Motors will be free from defects for one (1) year after delivery.
6. All other components for Case Tapers and Case Erectors will be free from defects for one (1) year after delivery.

If any part is proven defective within its warranty period then the exclusive remedy and Intertape's and the seller's sole obligation shall be, at Intertape's option, to repair or replace the part, provided the defective part is returned immediately to Intertape's factory or an authorized service station designated by Intertape.

A part will be presumed to have become defective after its warranty period unless the part is received or Intertape is notified of the problem no later than five (5) calendar days after the warranty period.

If Intertape is unable to repair or replace the part within a reasonable time then Intertape, at its option, will replace the equipment or refund the purchase price. Intertape shall have no obligation to install the repaired or replacement part.

Intertape shall have no obligation to provide or pay for the labor required to install the repaired or replacement part. Intertape shall have no obligation to repair or replace (1) those parts failing due to: operator misuse, carelessness, or due to any accidental cause other than equipment failure, or (2) parts.

1. Failure or damage is due to misapplication, lack of proper maintenance, abuse, improper installation or abnormal conditions such as temperature, moisture, dirt or corrosive matter, etc.
2. Failure due to inadequate cleaning, improper operating environment, improper utilities or operator error.
3. Failure due to operations above the rated capacities, or in any other improper manner, either intentional or otherwise.

4. Failure is due to equipment, which has been altered by anyone other than an authorized representative of Intertape Polymer Group.
5. Failure is due to an attempt by the purchaser to correct alleged defective equipment. In this event the purchaser is responsible for all expenses incurred.

LIMITATION OF LIABILITY: Intertape and seller shall not be liable for direct, indirect, special, incidental or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability or any other legal theory.

The foregoing Equipment Warranty and Limited Remedy and Limitation of Liability may be changed only by written agreement signed by authorized officers of Intertape and seller.

1.6 DESCRIPTION OF USA2024-WAT-EU CASE SEALER

This machine is designed to provide years of trouble free operation. If any problems arise with this machine during the normal course of operation, your properly trained and qualified internal service personnel should be able to repair any issues after consulting the Troubleshooting section of this manual.



Figure 1-1 USA2024-WAT-EU Case Sealer

The USA2024-WAT-EU Case Sealer is designed to apply Intertape brand water-activated tape to the top and bottom center seam of regular slotted corrugated cartons. The USA2024-WAT-EU Case Sealer is manually adjustable to a random variety of case sizes (see [Carton Specifications](#), page 3-3). The USA2024-WAT-EU Case Sealer features reversible operator controls to facilitate its adaptation into an existing conveyor line.

1.7 OPTIONAL EQUIPMENT




Figure 1-2 Optional Equipment

Chapter 2

IMPORTANT SAFEGUARDS







2.1 SAFETY LABELS




There are a number of safety labels used on the USA2024-WAT-EU Case Sealer. These labels are placed at different locations on the machine to warn operators and service personnel of possible dangers (refer to [Figure 2-1](#)). Please read the labels on the machine and the following safety precautions before using the machine.



- ✓ **Read this manual for other important safety operating and service information.**
- ✓ **Only trained personnel are to operate machine.**
- ✓ **Only fully qualified technicians are to service this machine.**
- ✓ **Wear safety glasses.**
- ✓ **Shut off power to machine before adjusting machine or loading & threading tape heads.**
- ✓ **Disconnect electrical power and compressed air (where applicable) before servicing.**
- ✓ **Follow Lock Out/Tag Out Procedures BEFORE servicing any machinery.**
- ✓ **All covers and guards must be in place before operating.**
- ✓ **Stay clear of moving parts which can shear and cut.**

Note: Should any of the safety labels placed on the Case Sealer be damaged or destroyed, replacements are available through your distributor.

2.3 SAFETY LABEL DESCRIPTIONS

<p>The label shown is affixed to the upper tape head assembly on both sides of the machine. It warns operators and service personnel of the presence of the cutting blade that may not be visible. Caution should be exercised when approaching this area.</p>	 <p>WARNING Blade hazard. Keep hands clear. Follow lock-out procedures before servicing.</p>
<p>The label shown is affixed to the upper tape head assembly on either side of the machine. It warns operators and service personnel of the presence of the cutting blade that may not be visible. Caution should be exercised when approaching this area.</p>	
<p>The label shown is affixed to the bridge above the vertical intake. It warns the operator of potential pinch points between the top and bottom of the case. Keep hands away from this area when processing a case.</p>	
<p>The label shown is located on the in-feed and exit ends of the machine belt drives. The label warns the operators and service personnel of the pinch points at each end of the belt drives.</p>	 <p>WARNING Moving machine parts can crush, cut and shear. Disconnect and lockout all power before servicing machine. Failure to follow the above can result in severe personal injury.</p>
<p>The label shown is affixed to the electrical control box. The label warns the service personnel to unplug the power supply before attempting any service work on the case sealer.</p>	 <p>WARNING Hazardous voltage. Disconnect power before servicing.</p>
<p>The label shown is affixed to the electrical control box. The label advises service personnel to connect the machine to a properly grounded outlet.</p>	 <p>CAUTION To provide continued protection against risk of electric shock, connect to properly grounded outlets only.</p>

<p>The label shown is located on the side of the column. This label provides convenient safety instructions for the operator and service personnel in the operation of the Intertape Case Sealing Equipment.</p>	 <p>WARNING</p> <p>OPERATION / SERVICE</p> <ul style="list-style-type: none"> • Only trained people are to operate and service machine. • Shut off power to machine before adjusting. • Unplug electrical power before servicing. <p>MACHINE MANUAL</p> <p>For other important safety, operating and service information read this machine's manual.</p> <p>EYE HAZARD</p> <p>Wear Safety Glasses which conform to ANSI Std. Z87.1 or EN 166</p> <p>COVERS AND GUARDS</p> <p>All covers and guards must be in place before operating machine.</p> <p>COMPRESSED AIR</p> <p>Lock-out source and bleed off pressure before servicing equipment.</p> <p>ELECTRICAL SHOCK</p> <p>Hazardous voltages may cause personal injury. Only authorized and qualified personnel are to service electrical enclosures.</p> <p>FAILURE TO FOLLOW THE ABOVE COULD RESULT IN SEVERE INJURY.</p>
<p>The label shown is located on the in-feed end of the machine. The label advises personnel about the dangers of the machine due to compressed air used in the system. Be aware of warnings and proper procedures when running and/or servicing the machine.</p>	 <p>DANGER</p> <p>COMPRESSED AIR BEWARE OF SERIOUS INJURY OR DEATH</p> <p>1) DO NOT USE COMPRESSED AIR FOR ANY OTHER PURPOSE THAN THAT FOR WHICH IT IS PROVIDED.</p> <p>2) NEVER DIRECT A STREAM OF COMPRESSED AIR TOWARDS YOUR BODY OR THE BODY OF ANOTHER PERSON.</p> <p>3) DO NOT USE COMPRESSED AIR TO COOL YOURSELF OR TO BLOW DUST FROM THE CLOTHES OR HAIR.</p> <p>3) NEVER INDULGE IN SO-CALLED "PRACTICAL JOKE" WITH COMPRESSED AIR.</p>
<p>The label shown is located on the gear side of the machine. The label warns the operators and service personnel of the pinch points.</p>	

<p>The label shown is located on the chain side of the machine. The label warns the operators and service personnel of the pinch points.</p>	
<p>The label shown is located on the side of the outfeed table. The label warns the operators and service personnel to keep fingers clear of lower tape mandrel.</p>	
<p>Note: Should any of the safety labels placed on the Case Sealer be damaged or destroyed, replacements are available through your distributor.</p>	

2.4 EXPLANATION OF SIGNAL WORD CONSEQUENCES

⚠ WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury or property damage.

⚠ CAUTION: Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury or property damage.

⚠ WARNING

- **To reduce the risk associated with mechanical, pneumatic, and electrical hazards:**
 - a. Read, understand, and follow all safety and operating instructions before operating or servicing the case sealer.
 - b. Allow only properly trained and qualified personnel to operate and service this equipment.
- **To reduce the risk associated with pinches, entanglement, and hazardous voltage:**

Turn electrical supply off and disconnect before performing any adjustments, maintenance, or servicing of the machine or taping heads.
- **To reduce the risk associated with pinches and entanglement hazards:**
 - a. Do not leave the machine running while unattended.
 - b. Turn the machine off when not in use.
 - c. Never attempt to work on any part of the machine, load tape, or remove jammed boxes from the machine while the machine is running.
- **To reduce the risk associated with hazardous voltage:**

Position electrical cord away from foot and vehicle traffic.
- **To reduce the risk associated with sharp blade hazards:**

Keep hands and fingers away from tape cutoff blades. Blades are extremely sharp.
- **To reduce the risk associated with fire and explosion hazards:**

Do not operate this equipment in potentially flammable/explosive environments.
- **To reduce the risk associated with muscle strain:**
 - a. Use the appropriate rigging and material handling equipment when lifting or repositioning this equipment.
 - b. Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift.

⚠ CAUTION

- **To reduce the risk associated with pinch hazards:**
 - a. Keep hands clear of the upper head support assembly as boxes are transported through the machine.
 - b. Keep hands, hair, loose clothing, and jewelry away from box compression rollers.
 - c. Always feed boxes into the machine by pushing only from the end of the box.
 - d. Keep hands, hair, loose clothing, and jewelry away from moving belts and taping heads.

2.5 OPERATOR SKILL LEVEL DESCRIPTIONS

Important: The area supervisor must ensure that the operator has been properly trained on all machine functions before operating the machine.

2.5.1 Skill “A” Machine Operator

This operator is trained to use the machine with the machine controls. This operator can feed cases into the machine, make adjustments for different case sizes, change tapes, and start/stop, and re-start production.

2.5.2 Skill “B” Mechanical Maintenance Technician

This technician is trained to use the machine as the machine operator, and is able to work with the safety protection disconnected, check and adjust mechanical components, perform maintenance operations, and repair the machine. He is not allowed to work on live electrical components.

2.5.3 Skill “C” Electrical Maintenance Technician

This technician is trained to use the machine as the machine operator, and is able to work with the safety protection disconnected, check and adjust mechanical components, perform maintenance operations, and repair the machine. He is allowed to work on live electrical panels, terminal blocks, and control equipment.

2.5.4 Skill “D” Manufacturer’s Technician

Skilled technician sent by the manufacturer, or its agent, to perform complex repairs or modifications, when agreed to by the customer.

Operator’s Skill Level Required to Perform the Following Tasks on the Machine

Operation	Machine Condition	Operator Skill Level	Number of Operators
Machine Installation & Set-Up	Running with Safety Protections Disabled	B & C	2
Tape Roll Replacement	Stopped by Pressing the Emergency Stop Button	A	1
Blade Replacement	Electrical Power Disconnected	B	1
Drive Belt Replacement	Electrical Power Disconnected	B	1
Ordinary Maintenance	Electrical Power Disconnected	B	1
Extraordinary Mechanical Maintenance	Running with Safety Protections Disabled	D	1
Extraordinary Electrical Maintenance	Running with Safety Protections Disabled	C	1

Notes

Chapter 3

SPECIFICATIONS

3.1 MACHINE DIMENSIONS

Machine Weight: 1182 lbs (536kg) crated




Figure 3-1 Machine Dimensions

3.2 MACHINE COMPONENTS



Figure 3-2 Machine Components

3.3 MACHINE OPERATING CONDITIONS

Always operate the machine in a dry, relatively clean environment at 40-105° F (5-40° C) with clean, dry cartons. Machine must be set on a level surface or adjusted to operate on a level plane.

3.3.1 Power Requirements

- Electrical - 220 V, 50 HZ, 10A
- Compressed Air – 90 PSI

This machine comes standard with two gear motors, one on each drive base, an electrical box, and a control box.

The electrical box contains an HMI for machine adjustments. The control box contains the Start button, the Emergency Stop switch, a Manual/Auto switch, a Tape Threading/Stop button, a Belt Drive button, a Tape Feed button, a Cut Tape button, a Clear button, and a Top/Both/Bottom selector switch.

A 12 ft (365.8cm) standard, three-conductor power cord with plug is provided. The receptacle providing this service must be properly grounded.

3.3.2 Operating Speed

Actual production rate is dependent on operator's dexterity and the case size mix. Boxes must be separated by 14 in. (355.6mm). Belt speed is 70 ft/min.

3.3.3 Tape Specifications

Use IPG Water-Activated Tape. The machine can accommodate tape widths of 2 - 3 in. (48 - 75mm).

A maximum tape roll length of 4500 ft can be installed on the tape heads. This machine can accommodate all Intertape brand, water-activated tape within listed specifications.

The standard tape leg length of 3 in. (76.2mm) is factory set. The standard tape leg length may vary up to ¼" (6mm) based on tape tension and line speed.

The standard tape leg length is adjustable via the HMI on the electrical box. The minimum tape leg length recommended is 2 in. (48mm) and the maximum recommended is 3 in. (76.2mm).

3.3.4 Carton Specifications

Type

- Regular Slotted Containers (RSC)
- Other style cases may be processed. Consult factory for details.

Material

125 - 275 PSI Bursting Test, Single or Double Wall B or C Flutes.

Weight

85 lbs (38.6kg) maximum

Size

The case sealer can accommodate most cartons within the size ranges listed below.

Case Size			
Carton Size	Length	Width	Height
Minimum	6 in. (152mm)	6.5 in. (165mm)	5 in. (127mm)
Maximum	Infinite	20 in. (508mm)	24 in. (610mm)

3.3.5 Case Processing Stability

For optimal performance, the cases should be stable when processing through the machine. Unstable cases may tilt backwards upon contact with the upper tape head causing the machine to jam.

If the box length (in direction of seal) to box height ratio is 0.75 in. (19.1mm) or less then several boxes should be test run to ensure proper machine performance. The formula is as follows:

$$\text{CARTON LENGTH IN DIRECTION OF SEAL} > 0.75 \text{ in. (19.1mm)} \div \text{CARTON HEIGHT}$$

Chapter 4

SET-UP PROCEDURES

4.1 RECEIVING AND HANDLING

The machine is shipped to the customer affixed to a pallet. The machine is enclosed with either a corrugated sleeve and cap or an HSC corrugated box. The sequence below is step by step instructions to remove all packing materials.

- Remove the strapping that secures the corrugated sleeve and cap, or HSC corrugated box, to the pallet.
- Lift off the cap and corrugated sleeve or HSC corrugated box.
- Remove protective wrapping from machine.
- Remove or relocate all securing devices such as tie wraps or locking collars.
- Remove the mounting bolts that secure the machine to the shipping pallet.
- Remove machine from the pallet to the location of final installation.




Figure 4-1 Receiving and Handling

All contents must be verified upon receipt. The following items are included with each machine:

- USA2024-WAT-EU Case Sealer
- Operation Manual & Parts List
- Plastic bag containing tape head spare parts.

Note: After unpacking the USA2024-WAT-EU Case Sealer, look for any damage that may have occurred during shipping. Should the case sealer be damaged, file a claim with the transport company and notify your authorized Intertape distributor.

4.2 CASTER INSTALLATION (IF PURCHASED)

⚠ WARNING: Caster installation requires raising the machine to access the bottom of each leg. Follow all possible safety procedures prior to and during this process.

1. With a forklift, raise the machine to allow access to the bottom of each leg.
2. Screw a caster into each leg until it is firmly seated to the bottom of the leg (refer to Figure 4-2).
3. Tighten each caster.
4. **Do not adjust the conveyor height by adjusting the caster.** Proper conveyor height must be achieved by adjusting the leg extension of each leg (refer to [Figure 4-3](#)).




Figure 4-2 Caster Installation

4.3 MACHINE HEIGHT ADJUSTMENT

⚠ WARNING: Machine height adjustment requires raising the machine to adjust each leg. Follow all possible safety procedures prior to and during this process.

The USA2024-WAT-EU Case Sealer must be installed on near-level ground. Use the adjustable legs to ensure that the machine is level and firmly on the ground (no rocking). Adjust the leg height with the four telescopic extension legs to accommodate conveyor heights from 24 - 30 in. (61.0 - 76.2cm).

1. To adjust the height of the Case Sealer, use a forklift to raise the machine to give ample room to extend the legs.
2. Using a 19mm box end wrench, loosen eight 12mm hex head adjustment bolts (refer to Figure 4-3).
3. Adjust the legs to the desired conveyor height and tighten bolts. Etched lines on the legs ease leveling.




Figure 4-3 Machine Height Adjustment

4.4 INSTALLATION OF INTERPACK BRAND IN-FEED ROLLER TABLES (IF PURCHASED)




Figure 4-4 Case Direction

1. Loosely install two carriage bolts into top two mounting holes on roller table with hardware included (refer to Figure 4-5).




Figure 4-5 Carriage Bolt Installation

- Utilizing the slots on the machine base, attach roller table to machine base by locating carriage bolts in slots on machine base and push down to lock in place (refer to Figure 4-6). Make sure carriage bolts are properly aligned into slot when pushed down to lock in place before proceeding.




Figure 4-6 Roller Table to Machine Base Installation

- Once roller table is attached to the machine base using the two carriage bolts, install remaining two carriage bolts with hardware included through the bottom two holes on the machine base and roller table (refer to Figure 4-7).




Figure 4-7 Remaining Carriage Bolt Installation

- After all four mounting studs and included hardware have been installed, tighten all hardware to avoid roller table instability then install rollers on table.

4.5 INSTALLATION OF EXTERNAL IN-FEED AND EXIT CONVEYORS

1. Customer supplied in-feed conveyor (if used) should provide straight and level entry into the case sealer.
2. Customer supplied gravity exit conveyor (if used) should be straight and declined no more than 20mm/meter away from the machine to convey the sealed cartons away from the machine.
3. Customer supplied powered exit conveyor should be straight and level to convey the sealed cartons away from the machine.




Figure 4-8 Installing In-Feed and Exit Conveyors

4.6 CONNECTING UTILITIES

4.6.1 Electrical Utilities

A 12 ft (365.8cm) standard three-conductor power cord with plug is provided. The receptacle must be properly grounded. Before the machine is plugged into the receptacle, ensure that all materials are removed from the machine. The electrical control is protected with an automatic circuit breaker with resettable overload.

The electrical box is located on one side of the USA2024-WAT-EU Case Sealer. It contains an HMI that can be used to adjust machine operation settings as needed.

The control box contains a Start button, the Emergency Stop switch, a Manual/Auto switch, a Tape Feed/Cut button, a Belt Drive button, a Tape Feed button, a Cut Tape button, a Clear button, and a Top/Both/Bottom selector switch (refer to [Figure 4-11](#)).




Figure 4-9 Electrical Utilities

Note: Moving the control box to the opposite side of the machine requires disconnecting and reconnecting electrical wires and components. Only trained and qualified service technicians should access an open control box. Follow all possible safety procedures prior to and during this process.

4.6.2 Pneumatic Utilities

Note: The pressure setting for the main air regulator is factory set. The values will need to be adjusted as needed by customer supplied pressure and volume.

The main air regulator has a male quick disconnect adaptor (refer to Figure 4-10). Connect clean dry compressed air to this adaptor. The USA2024-WAT-EU Case Sealer requires a minimum of 9 CFM at 90 PSI.

To regulate the main air pressure, pull on the knob located on the top of the main air regulator. Turn the knob clockwise for more pressure and counterclockwise for less. When the air pressure is at 90 PSI, push back down on the button until a "click" is felt to lock it in position. The thread size is 3/8 NPT.

Note: Should the supplied airline or pressure be unplugged or cut for any reason, tape will not feed and rollers will not be activated if box is processed.



Figure 4-10 Main Air Regulator

4.7 OPERATOR CONTROL BOX

Make sure machine is connected to air supply of at least 90 PSI and machine regulator is set at 90 PSI. The following describes the use of control box buttons:

1. Power Lamp – Electricity is being delivered throughout the machine.
2. Manual Mode/Auto Mode
 - a. Auto Mode is for machine production operation.
 - b. Manual Mode is for tape threading/troubleshooting.
3. Start
 - a. On Auto Mode, starts machine operation.
 - b. No function on Manual Mode.
4. Tape Threading/Stop
 - a. On Auto Mode, stops machine operation.
 - b. On Manual Mode, engages/disengages pinch roller which drives the tape.
5. Belt Drive
 - a. No function on Auto Mode.
 - b. On Manual Mode, jobs side belt drives.
6. Top/Both/Bottom
 - a. On Auto Mode, selects the seams of the box to be taped.
 - b. On Manual Mode, selects which tape head dispenses tape.
7. Tape Feed
 - a. No function on Auto Mode.
 - b. On Manual Mode, feeds tape on tape heads.
8. Cut Tape
 - a. No function on Auto Mode.
 - b. On Manual Mode, engages cutting mechanism in tape head to cut tape.
9. EMG. Stop
 - a. On Auto Mode, de-energizes machine.
 - b. On Manual Mode, de-energizes machine.
10. Reset

Used to reset machine after clearing a jam.
11. Clear (Operational in Auto Mode only)

This button is used to simplify clearing a jam during production. When pressed down, belt drive motors stop, air supply is removed from tape head, and cutting mechanism is engaged. When pressed a second time, machine will feed preset length of tape and cut it to make sure there is no jammed tape.




Figure 4-11 Operator Control Box

4.8 OPERATOR CONTROL BOX RELOCATION

Moving the control box to the opposite side of the machine requires detaching and reattaching the control box from the columns and reconnecting electrical wires and components

Note: Only trained and qualified service technicians should perform the relocation. Ensure that you follow all possible safety procedures prior to and during this process.

1. Disconnect machine from electrical supply.
2. Remove front panel from control box.
3. Remove four screws attaching control box to the column.
4. Remove control box and relocate to opposite column.
5. Route control box and wire conduit to opposite side of machine.
 - a. Remove wire ties holding wires under machine.
 - b. Install new wire ties to secure wires to machine base.
6. Attach control box to opposite column using the four screws.
7. Attach front panel to control box.




Figure 4-12 Control Box Relocation

4.9 TOP TAPE HEAD LOADING/THREADING

4.9.1 Direction of Top Tape Unwind

As shown in the diagram below, tape should be mounted with a counterclockwise, unwind direction. The adhesive side of tape will be facing up as it goes around the peel-off roller.

4.9.2 Top Tape Path

The diagram below shows the threaded tape path using the red line/arrow as the tape. Use Figure 4-13 and steps on page 4-12 for proper tape threading. The order in which the tape passes the rollers starts at the peel-off roller, travels through three guide rollers as labeled below then over powered roller.




Figure 4-13 Top Tape Threading Diagram

4.9.3 Top Tape Threading/Loading Instructions

The instructions below will assist in threading tape on the top tape head. Top Threading diagram is located on page 4-11.

1. Put machine in Manual Mode using Manual/Auto selector switch (1, Figure 4-14).
2. Install tape roll on to mandrel making sure the unwind direction is counterclockwise (refer to page 4-11).
3. Pull tape around peel-off roller and towards the front of the machine (6, Figure 4-15).
4. Bring tape around the front of the first guide roller (8) followed by bringing the tape back towards the second guide roller (9).
5. After threading around second guide roller, pass tape under the third roller (7) and pull towards the front of the machine.
6. Bring the tape over the powered drive roller (6) and towards pinch roller (10).
7. Thread tape under guide plate until it reaches the pinch roller (10). During this process, make sure pinch roller is not engaged. To engage/disengage the pinch roller, use the Tape Threading/Stop button (2, Figure 4-14) located on the control box.
8. Once tape has been passed under the pinch roller, engage pinch roller using Tape Threading/Stop button.
9. Press down the Tape Feed button (4) to allow machine to pass tape through tape shoe and feed out of the tape head.
10. If tape passes with no jams, press down the Cut Tape button (3) then remove tape from tape shoe guide, switch machine to Auto (1), and press Start button (5) and hold for one second to begin machine operation. If you encounter a jam, see [Clear Mode \(Clear Jam\)](#), on page 5-7.




Figure 4-14 Control Box – Top Threading




Figure 4-15 Top Tape Head Loading/Threading

4.10 BOTTOM TAPE HEAD LOADING/THREADING

4.10.1 Direction of Bottom Tape Unwind

As shown in the diagram below, tape should be mounted with a clockwise, unwind direction. The adhesive side of tape will be facing down as it goes around the peel-off roller.

4.10.2 Bottom Tape Path

The diagram below shows the threaded tape path using the red line/arrow as the tape. Use Figure 4-16 and the steps on page 4-14 for proper threading of tape. The order in which the tape passes the rollers starts at the peel-off roller, travels through three guide rollers, as labeled below, then over powered roller, and under a fourth guide roller.




Figure 4-16 Bottom Tape Threading Diagram

4.10.3 Bottom Tape Threading/Loading Instructions

The instructions below will assist in threading of tape on the top tape head. Bottom Threading diagram is located on page 4-13.

1. Put machine in Manual Mode using Manual/Auto selector switch (1, Figure 4-17).
2. Install tape roll onto mandrel making sure the unwind direction is clockwise (refer to page 4-13). To move mandrel to tape roll installation position, pull locking lever to unlock mandrel slide handle (5, Figure 4-18) then pull handle outward. After tape roll has been installed, move mandrel to running position by pushing mandrel slide handle inward and securing with locking lever.
3. Pull tape around peel-off roller and towards the front of the machine with adhesive side facing down (6, Figure 4-19).
4. Thread tape over the first guide roller (7), bring tape around and under the second guide roller (8), and pull towards the front of the tape head.
5. After threading through the second guide roller, pass tape over powered roller (10), pull under third guide roller (9), and bring tape up to the pinch roller (11). Ensure pinch roller is not engaged, using the Tape Threading/Stop button (2, Figure 4-17) to engage/disengage the pinch roller.
6. Once tape has been passed under the pinch roller, engage pinch roller using Tape Threading/Stop button (2).
7. Press down the Tape Feed/Cut button (3) to allow machine to pass tape through tape shoe and feed out of the tape head.
8. If tape passes with no jams, remove tape from tape shoe guide, switch machine to Auto (1), press Start button (4), and hold for one second to begin machine operation. If you encounter a jam, see [Clear Mode \(Clear Jam\)](#) on page 5-7.




Figure 4-17 Control Box – Bottom Threading




Figure 4-18 Mandrel Slide Handle




Figure 4-19 Bottom Tape Head Loading/Threading

4.11 ADDING WATER TO THE SYSTEM

1. Remove the water bottles by pulling them straight up from support brackets (refer to Figure 4-20).
2. Turn the bottles over so the water will not spill.
3. Unscrew the valve assembly and remove.
4. Fill the bottle with warm water.
5. Replace the valve assembly.
6. Install the water bottle by inserting it over the water pot post and into the support brackets located on the machine.




Figure 4-20 Adding Water to the System

Notes

Chapter 5

OPERATING INSTRUCTIONS

5.1 INTRODUCTION TO OPERATING INSTRUCTIONS

Once the tape has been loaded and threaded on both the top and bottom, allow up to 10 minutes of being powered on for the machine to become completely ready to process regular slotted cases. The following instructions are presented in the order recommended for processing cases successfully through the USA2024-WAT-EU Case Sealer.

1. Install and thread tape roll on the top and the bottom of the machine (refer to [Top Tape Head Loading/Threading](#) and [Bottom Tape Head Loading/Threading](#)).
2. Fill water bottles and place them on machine (refer to [Adding Water to the System](#)).
3. Open water pot valves on the top and bottom tape heads – make sure water line is connected to the water pot (water pot valves can be identified in sections [7.5](#) and [7.6](#)).
4. The top tape head water line must be purged to allow proper water flow into water pot. Remove the water pot from the tape head and lower it until water starts flowing into the water pot. Introduce water pot into tape head.
5. Supply or connect machine to air line, verify that the machine is set to 90 PSI.
6. Supply or connect machine to 220 VAC electrical supply.
7. Turn on main power disconnect switch located on machine electrical box.
8. Twist both E-stops, on the control box and the outfeed conveyor, clockwise to release and allow machine operation (refer to [Figure 5-1](#)).
9. Set machine to Manual Mode using Manual/Auto selector switch on the control box (refer to [Figure 5-14](#)).
10. Press Tape Feed button to feed a predetermined length of tape through the path. Tape will be cut once length of tape has been fed (refer to [Figure 5-14](#)).
11. Inspect dispensed tape to ensure water is being properly applied to adhesive side. If water is not being properly applied, refer to Chapter 6, [Troubleshooting](#).
12. Switch machine to Auto using Manual/Auto selector switch on the control box (refer to [Figure 5-14](#)).
13. Press Start button on the control box, and hold for one second to begin machine operation (refer to [Figure 5-14](#)).
14. Introduce a case to the machine indexing gate.
15. Once box has been processed, machine is ready for production.




Figure 5-1 E-stop Locations

5.2 CASE SIZE SET-UP FUNCTIONS




Figure 5-2 Case Size Set-Up

5.3 INITIAL CONDITION

1. Using the height adjustment handle, raise the upper head, as shown in Figure 5-3.
2. Using the width adjustment handle, open side drives or centering guides, as shown in Figure 5-4.
3. Loosen each locking knob and open top squeezers, as shown in Figure 5-5.




Figure 5-3 Raise Upper Head




Figure 5-4 Open Side Drives




Figure 5-5 Open Top Squeezers

5.4 PREPARING CASE TO BE PROCESSED

5.4.1 Flap Folding

1. Fold minor flaps inward, as shown in Figure 5-6.
2. Fold major flaps inward, as shown in Figure 5-7.




Figure 5-6 Fold Minor Flaps




Figure 5-7 Fold Major Flaps

5.4.2 Overfills and Voids

Overfills and Void Fills, as shown in Figures 5-8 and 5-9, should be avoided to assure proper processing of the corrugated case. Each of these scenarios put stress on the pressure sensitive tape seal which could be detrimental to the integrity of the closure.




Figure 5-8 Overfill




Figure 5-9 Void Fill

5.5 CASE HEIGHT ADJUSTMENT

1. Insert the case to just before lower tape head, as shown in Figure 5-10.
2. Move locking handle to unlock position. Turn case height handle, as shown in Figure 5-11, to lower the upper head until it contacts top of case. Upper head should contact case firmly enough to keep major flaps closed but not restrict processing of case or score the top of case. Move locking handle to locked position.




Figure 5-10 Insert Case




Figure 5-11 Adjust Upper Head

5.6 CASE WIDTH ADJUSTMENT

Turn case width handle, as shown in Figure 5-12, until side drive belts contact case. Side drive belts should contact the case firmly enough so case processes smoothly but not so firm as to score the side of the case.




Figure 5-12 Case Width Adjustment

5.7 TOP SQUEEZER ADJUSTMENT

Slide each top squeezer to contact the case firmly and tighten each locking knob, as shown in Figure 5-13. Each top squeezer should be firm enough on the case to completely close any gap on the center seam but not so firm as to restrict the smooth processing of the case.




Figure 5-13 Top Squeezer Adjustment

5.8 CONTROL BOX

Once the tape has been loaded on both the top and bottom and threaded (refer to [Top Tape Head Loading/Threading](#) on page 4-11 and [Bottom Tape Head Loading/Threading](#) on page 4-13), allow up to 10 minutes of being powered on for the machine to be completely ready to process regular slotted cases. The following instructions are presented in the order recommended for processing cases successfully through the USA2024-WAT-EU Case Sealer.

The USA2024-WAT-EU Case Sealer has three operating modes. The operator selects these modes, using the 2-position switch and push button on the Control Box (refer to Figure 5-14).




Figure 5-14 Control Box

5.8.1 Auto Mode

This is the standard operating mode of the machine. In this mode, when a case is being processed, the side belts will process a case and then tape is applied to the top and bottom center seams of the case.

1. Ensure that the compressed air is plugged and at 90 PSI.
2. Turn the Manual/Auto selector switch on the control box to Auto (Automatic) (refer to Figure 5-14).
3. Using adjustment handles, set the height of the upper head to match case height and set the side belts to match the width of case to be processed.
4. Press the Start button and hold for one second; the drive belts will start.
5. Introduce a case with the flaps held in the closed position and advance to the indexing gate so the proper sensor is activated. Do not place hands in front of case.
6. The case will be processed and tape applied to top and bottom center seams.
7. Once the case is processed and exits the machine, the indicator light at the front of the machine will change from red to green indicating that the machine is ready for another case to be processed.

5.8.2 Manual Mode

This mode is used for troubleshooting and loading tape on to machine.

1. Ensure that the compressed air is plugged in and at 90 PSI.
2. Turn the control selector to Manual Mode (refer to Figure 5-14).
3. Once set to Manual, other buttons on control box can be used for troubleshooting or loading tape.
4. See [Operator Control Box](#), on page 4-9, for an explanation of button usage.

5.8.3 Clear Mode (Clear Jam)

This mode is used to clear a jammed box without the need for the e-stop.

Note: While in Clear Mode, the belts will cease operation but the machine will continue to be powered throughout. If electricity needs to be cut off throughout the machine, use the E-stop buttons located on the control box and on the top tape head box.

1. Ensure that the compressed air is plugged in and at 90 PSI.
2. Press downward on the Clear Mode button, at the top of the control box, to set machine to Clear Mode (refer to Figure 5-14).
3. Remove jammed box.
4. Determine location of tape jam:
 - a. Inspect and remove tape shoe if there is visible tape in path (refer to [page 7-7](#)).
 - b. Inspect and remove water pot to clear any tape that may remain from jam (refer to [page 4-15](#)).
 - c. Inspect tape path prior to cutter for jam, pressing down on the pinch roller to remove any remaining tape.
5. Once box and tape have been removed, feed tape under pinch roller.
6. Pressing the Clear Mode button a second time will feed a preset length of tape and cut. If no tape is dispensed, refer to Chapter 6, [Troubleshooting](#).
7. Remove newly dispensed tape, press Start button, and hold for one second to begin machine operation.



WARNING: Ensure that the operator's hands are away from the moving belts of the side drive base assembly. Do not place hands on the front edge of the case while it is entering the machine.

Note:

- Should any problem occur during processing that requires halting the machine, press any red E-stop button.
- The machine should **never** be washed down or subjected to conditions causing condensation on components.

Notes

Chapter 6

TROUBLESHOOTING

The USA2024-WAT-EU Case Sealer is fabricated with high quality components that provide trouble-free operation for a long period of time. However, should a problem occur, we recommend that you consult the following table. If the problem you encounter is not discussed in this table, call Interpack [Technical Support](#).

Trouble	Possible Causes	Solutions
Green start button pressed but belts do not turn.	E-stops not reset. Machine not plugged in. Machine set to manual operation. Clear mode activated.	Rotate both E-stops ¼-turn clockwise (page 5-1). Plug machine into 220 V, 50 HZ, 10A electrical service. Switch machine to auto using selector switch (page 4-9). Press clear button on control box to deactivate clear mode (page 4-9).
Motors turn but belts do not turn.	Belt tension too low.	Adjust tension on drive belts (page 8-2).
Drive belts do not process cases.	Belt tension too low. Collapsed leading end panel on case. Case size is out of specification. Box slipping on drive belts.	Adjust tension on drive belts (page 8-2). Adjust pressure of wipe down rollers. Compare case sizes with machine specifications. Adjust width of side belt drives.
Case processes but side of case is crushed.	Case width adjustment incorrect.	Re-adjust case width (page 5-5).
Case processes but leading end panel is crushed.	Product does not support the end panel of the case. Too much pressure on wipe down rollers. Rear wipe arm activates before box is processed.	Insert proper dunnage material to provide support. Reduce pressure of wipe down rollers. Case slipping or box removed after introduction to sensor.
Drive belts start then stop.	Motor starter trips.	Call maintenance.

Trouble	Possible Causes	Solutions
Overfilled cases do not process properly.	Product height exceeds case height. Excessive void fill dunnage.	Reduce product in case to match case height. Increase case height to match product height. Reduce void fill dunnage to match case height.
Unstable cases do not process properly.	Case height exceeds 1 ½ times the case length.	Re-configure case dimensions so that case is not unstable.
Tape not centered on carton.	Thread path rollers adjustments are misaligned. Tape roll not fully pushed on tape mandrel. Dust and dirt on drive rollers.	Adjust width of thread path rollers. Push tape roll completely onto tape mandrel. Clean drive rollers.
Tape leg is too short/too long.	Loss of air causing tape feeding problems. Tape leg adjustment not correct. Tape is not threaded correctly.	Check inlet pressure and adjust as needed. Adjust tape leg using HMI on electrical box. Thread tape correctly (page 4-11 ; page 4-13).
Tape does not cut.	Debris in the cutter blade. Blade dull. Weak return spring. Tape is not threaded properly. Dislocated knife spring.	Clean cutter blade (page 7-7 ; page 7-8). Replace cutter blade (page 7-10). Replace return spring. Thread tape correctly (page 4-11 ; page 4-13). Re-attach knife spring.
Tape is jamming.	Debris in the tape path. Adhesive build up. Pressure plate missing or installed incorrectly. Tape dispensing guides set incorrectly; too tight or too loose. Roller too high or too low. Water pot not seated properly. Roller dry; no or low water pot level.	Clean tape path. Clean tape path, moistening brush/roller and water pot. Install pressure plate. Loosen or tighten tape dispensing guides. Adjust roller height. Re-seat water pot (page 4-15). Add water or adjust water bottle level (page 4-15).

Trouble	Possible Causes	Solutions
Tape is too dry.	<p>Worn roller.</p> <p>Water level in water pot too low.</p> <p>Water valve is off.</p> <p>Water pot not seated properly.</p> <p>Water bottle is out of water.</p> <p>Roller in water pot set too low.</p> <p>Machine not level on ground.</p>	<p>Replace roller.</p> <p>Adjust water level in water pot (page 4-15).</p> <p>Make sure valve is in the on position (page 7-5; page 7-6).</p> <p>Re-seat water pot (page 4-15).</p> <p>Refill water bottle (page 4-15).</p> <p>Adjust roller height in the water pot.</p> <p>Check level of machine and adjust as needed.</p>
Tape is not evenly moistened.	<p>Worn roller.</p> <p>Roller uneven in water pot.</p> <p>Water level too low.</p> <p>Machine not level.</p>	<p>Replace roller.</p> <p>Adjust set screws to make roller even.</p> <p>Adjust water bottle height (page 4-15).</p> <p>Make sure machine has been properly leveled on ground.</p>
No tape dispensed.	<p>Out of tape.</p> <p>Not threaded properly.</p> <p>Tape jam.</p> <p>Machine set to different operation condition.</p>	<p>Replace tape roll.</p> <p>Thread tape properly (page 4-11; page 4-13).</p> <p>Refer to Tape is jamming on page 6-2.</p> <p>Make sure correct setting is chosen between Top/Both/Bottom.</p>
Front or rear tape leg not sticking to the case.	<p>Too low water level.</p> <p>Tape threaded incorrectly.</p> <p>Case slipping on side belts.</p> <p>Insufficient air supply.</p> <p>Tape leg too short; timers set improperly.</p>	<p>Check and raise water bottle if water level is low (page 4-15).</p> <p>Thread tape correctly (page 4-11; page 4-13).</p> <p>Adjust drive belt width (page 8-2).</p> <p>Make sure regulator is reading the recommended 90 PSI.</p> <p>Adjust tape leg timer setting in HMI.</p>

Trouble	Possible Causes	Solutions
<p>Wrinkles on tape applied to the box.</p>	<p>Case not introduced to machine straight.</p> <p>Case is overfilled.</p> <p>Rear wipe down arm timing is off.</p> <p>Insufficient air supply.</p> <p>Tape tension is incorrect.</p> <p>Motor RPM is incorrectly set.</p> <p>Tape not threaded properly.</p>	<p>Make sure to introduce box in square and straight.</p> <p>Make sure case is not overfilled.</p> <p>Adjust rear wipe down arm timing in HMI.</p> <p>Make sure supply is at least 90 PSI and machine set to 90 PSI.</p> <p>Thread tape correctly (page 4-11; page 4-13).</p> <p>Adjust motor RPM in HMI.</p> <p>Thread tape correctly (page 4-11; page 4-13).</p>

Chapter 7

PREVENTIVE MAINTENANCE

7.1 MACHINE PREVENTIVE MAINTENANCE

The USA2024-WAT-EU Case Sealer has been designed and manufactured with the finest components to provide long, trouble-free performance. General preventive maintenance will improve performance and prolong the life of the case sealer. Review the illustrations and chart below for information regarding machine maintenance.

Figure 7-1 Machine Preventive Maintenance Chart

Item	Action Required	Material	Frequency		
			Weekly	Monthly	Quarterly
Carton Dust In/On Machine	Blow Off Machine Externally and Internally	Air hose	X		
	Pay Attention To Drive Base Centering Chain				
Hardware	Re-Tighten any Loose Hardware			X	
	Replace any Missing Hardware				
Column Shafts	Lubricate	Silicone Lubricant		X	
Cross Shafts	Lubricate	Silicone Lubricant		X	
Centering Chain	Lubricate	Chain Lubricant		X	
Air Regulator Filter	Clean Filter	Water, Mild Detergent		X	
Tape Path	Clean To Remove Adhesive	Water	X		
Water Pot/Reservoir	Rinse Out Thoroughly			X	
Wetting Roller	Clean Roller	Water, Mild Detergent		X	
Wipe Down Drive Rollers	Remove Dust	Air hose	X		

7.2 CLEANING THE MACHINE

⚠ WARNING: Exercise all safety precautions prior to starting this procedure. Disconnect electrical power and wear approved safety glasses.

7.2.1 Side Belt Drive Base

Insert an air nozzle along the top edge of the belt into the opening of the drive base and clean out any dust and dirt (refer to Figure 7-2).

7.2.2 Column Shaft

1. With a cloth, wipe down any accumulation of dust and dirt (refer to Figure 7-2).
2. Be sure to wipe down both columns.

7.2.3 Connecting Chain for Centering Assembly

Blow off any accumulation of dust and dirt from the connecting chain (refer to Figure 7-2).




Figure 7-2 Cleaning the Machine

7.3 CHANGING THE AIR REGULATOR FILTER

⚠ WARNING: Ensure that the case sealer has been disconnected from the power source and the airline before conducting any maintenance procedures.

The filter on the air regulator removes dirt and moisture from air plant before it enters the carton sealer.

1. To remove metal protective guard, press down on locking tab located towards the top of the guard, rotate guard and pull down (refer to Figure 7-3).
2. The clear reservoir has a threaded top, which is used to attach it to the main regulator assembly. To remove the reservoir, rotate it until unfastened (refer to Figure 7-4).
3. The air regulator filter is held in place using a threaded cap fastened on to the main assembly. To remove the filter, unfasten the cap and pull down on filter (refer to Figure 7-5).




Figure 7-3 Remove Guard




Figure 7-4 Remove Reservoir




Figure 7-5 Remove Filter

7.4 LUBRICATING THE MACHINE

7.4.1 Column Shaft

Lubricate both shafts with industrial grade silicone.

7.4.2 Acme Drive Base Shafts

Lubricate both shafts with light machine grease.

7.4.3 Centering Chain

Lubricate chain with chain lubricant.




Figure 7-6 Lubricating the Machine

7.5 REMOVING THE TOP TAPE HEAD

For cutter blade maintenance and replacement, removal of the tape heads is required for ease of access. Make sure tape has been removed from the top tape head before attempting to remove them from machine.

1. Remove quick-disconnect from the top of tape head, as shown on Figure 7-7.
2. Disconnect electrical connection of tape head by unhooking and removing plug, as shown in Figure 7-8.
3. Turn off flow of water by turning valve until it is perpendicular to flow of water and remove quick-disconnect to allow removal of water pot, as shown in Figure 7-9.




Figure 7-7 Quick-disconnect




Figure 7-8 Electrical Disconnect




Figure 7-9 Quick-disconnect

4. Remove water pot from tape head, as shown on Figure 7-10.
5. Pull hold-down plate upwards to allow for removal of tape head, as shown on Figure 7-11.
6. Pull tape head forward then up to remove from tape head box, as shown on Figure 7-12.




Figure 7-10 Remove Water Pot




Figure 7-11 Pull Hold-down Plate




Figure 7-12 Remove Tape Head Box

7.6 REMOVING THE BOTTOM TAPE HEAD

For cutter blade maintenance and replacement, removal of the tape heads is required for ease of access. Make sure tape has been removed from the bottom tape head before attempting to remove them from machine.

1. Remove side covers on both sides of tape head, as shown on Figure 7-13.
2. Disconnect electrical connection of tape head by unhinging and removing plug, as shown on Figure 7-14.
3. Turn off flow of water by turning valve until it is perpendicular to flow of water and remove quick-disconnect to allow removal of water pot, as shown on Figure 7-15.




Figure 7-13 Remove Side Covers




Figure 7-14 Electrical Disconnect




Figure 7-15 Quick-disconnect

4. Remove water pot from tape head, as shown on Figure 7-16.
5. Remove air quick-disconnect, as shown on Figure 7-17.
6. Lift tape head upwards to remove from tape head box, as shown on Figure 7-18.




Figure 7-16 Remove Water Pot




Figure 7-17 Quick-disconnect




Figure 7-18 Lift Tape Head

7.7 CLEANING THE CUTTER BLADE (TOP TAPE HEAD)

⚠ WARNING: The knife contained in the tape heads is extremely sharp. Use caution when threading the tape or performing maintenance to avoid injury.

1. Remove top cover from tape head, as shown in Figure 7-19.
2. Remove tape shoe and water pot from tape head, as shown in Figure 7-20, to gain access to cutter blade area.
3. While retaining the knife arm position, clean the blade on both sides using damp cloth and a mild detergent. Use caution as blade is extremely sharp.
4. Clean the striker plate using damp cloth and a mild detergent (refer to Figure 7-21).
5. Insert water pot and tape shoe.




Figure 7-19 Remove Top Cover




Figure 7-20 Remove Tape Shoe and Water Pot




Figure 7-21 Clean Striker Plate

7.8 CLEANING THE CUTTER BLADE (BOTTOM TAPE HEAD)

⚠ WARNING: The knife contained in the tape heads is extremely sharp. Use caution when threading the tape or performing maintenance to avoid injury.

1. Remove tape shoe and water pot from tape head, as shown in Figures 7-22 and 7-23, to gain access to cutter blade area.
2. While retaining the knife arm position, clean the blade on both sides using damp cloth and a mild detergent. Use caution as blade is extremely sharp.
3. Clean the striker plate using damp cloth and a mild detergent (refer to Figure 7-24).
4. Re-insert water pot and tape shoe.




Figure 7-22 Remove Tape Shoe




Figure 7-23 Remove Water Pot




Figure 7-24 Clean Striker Plate

7.9 CUTTER BLADE MAINTENANCE

⚠ WARNING: The knife contained in the tape heads is extremely sharp. Use caution when threading the tape or performing maintenance to avoid injury.

The cutter blade must raise when tape is being processed to allow the tape to proceed underneath. The blade must therefore raise and return without restriction (refer to Figure 7-25). Should the blade not raise and return when tape is processed, do the following:

1. Remove tape shoe from tape head.
2. Remove the water pot.
3. Observe to see when the blade raises that there is no hesitation or delay.
4. Observe to see that there is wide enough opening between cutter blade and the striker plate to allow the full tape width to pass through.
5. If no clearance is observed, clean the striker plate and cutter blade (see [page 7-7](#) or [page 7-8](#)).
6. If above does not fix the problem, please contact technical support.
7. Replace tape shoe and water pot.




Figure 7-25 Cutter Blade Maintenance

7.10 CUTTER BLADE REPLACEMENT

⚠ WARNING: The knife contained in the tape heads is extremely sharp. Use caution when threading the tape or performing maintenance to avoid injury.

1. Remove the tape shoe assembly.
2. Remove the water pot assembly.
3. Remove the upper guide plate.
4. Remove the three 4mm countersink hex screws with a 2.5mm hex key.
5. Remove the cutter blade (refer to Figure 7-26).
6. Remove the two 4mm screws on the striker plate with a 2.5mm hex key.
7. Remove the striker plate (refer to Figure 7-27).
8. Replace the cutter blade and striker plate.
9. Place the water pot assembly and upper guide plate back into tape head.




Figure 7-26 Striker Plate and Cutting Blade











Figure 7-27 Striker Plate




Chapter 8 **MACHINE MAINTENANCE & ADJUSTMENT**

8.1 DRIVE BELT REPLACEMENT

<p>Using a 4mm Allen key, remove two screws and remove drive base cover.</p>	
<p>Using appropriate Allen key and wrench, loosen belt tensioning bolts.</p>	
<p>Remove worn belt and replace with new belt.</p>	
<p>Using appropriate Allen key and wrench, tighten belt tensioning bolts.</p> <p>Be sure to equally adjust tensioning bolts for both drive belts.</p>	
<p>Proper belt tension is achieved when a 5-pound pull force is used to create a 1 in. (25mm) gap, as shown in the middle of the drive base.</p>	


<p>Intertape S/B drive idler pulleys are engineered to self-track to center.</p> <p>After tensioning, if the belts do not track on center, contact maintenance or your IPG distributor.</p>	
<p>Using a 4mm Allen key, replace drive base cover, as shown.</p>	

8.2 DRIVE BELT ADJUSTMENT


<p>Using a 4mm Allen key, remove two screws and remove drive base cover.</p>	
<p>Using appropriate Allen key and wrench, tighten belt tensioning bolts.</p> <p>Be sure to adjust upper and lower tensioning bolts equally.</p>	
<p>Proper belt tension is achieved when a 5-pound pull force is used to create a 1 in. (25mm) gap as shown in the middle of the drive base.</p>	

Intertape S/B drive idler pulleys are engineered to self-track to center.

After tensioning, if the belts do not track on center, contact maintenance or your IPG distributor.



Using a 4mm Allen key, replace drive base cover as shown.



Notes

Chapter 9

ILLUSTRATED PARTS LIST


List of Assemblies

Section	Name	Page
9.1	USM0868 - USA2024-WAT-EU Top Level Assembly	9-4
9.2	UAM5012 – Bridge Assembly	9-6
9.2.1	UAM0513 – Bridge Base Assembly	9-8
9.2.2	USM0907 – Top Tape Head Water Bottle Assembly	9-10
9.2.3	USM0391 – Single Lock Assembly	9-11
9.2.4	UAM0471 – Compression Guide Assembly, Left Hand	9-12
9.2.5	USM0823 – Compression Guide Assembly, Right Hand	9-13
9.2.6	USM7585 – Top Tape Carriage Assembly	9-14
9.2.6.1	UAM0479 – Dancer Arm Assembly	9-15
9.2.6.2	UAM0195 – Mandrel Hub	9-16
9.3	UAM0487 – Column Assembly, Right Hand	9-18
9.4	UPM5987 – Column Assembly, Adjustable, Left Hand	9-20
9.5	UAM0488 – Control Box	9-22
9.6	UAM0489 – Output Table	9-24
9.6.1	UAM0504 – Output Table Top	9-26
9.6.2	UAM0506 – BTM Tape Carriage	9-28
9.6.3	UPM6039 – Tape Roll Carriage	9-30
9.7	USM0867 – Base Assembly	9-32
9.7.1	UAM0485 – Pneumatic Assembly	9-34
9.7.2	UAM0503 – Electrical Box	9-36
9.7.3	UAM0483 – Inlet Stop Assembly	9-38
9.7.4	UAM0482 – Lower Host Base Assembly	9-39
9.7.5	USM0901 – Water Bottle Unit Assembly	9-40
9.7.6	UAM0478 – Outlet Table Assembly	9-42
9.7.7	UAM0477 – Roller Assembly, Right Hand	9-44
9.7.8	UAM0474 – Roller Assembly, Left Hand	9-45
9.7.9	UAM0473 – Inlet Table Assembly	9-46
9.7.10	UAM0468 – Frame Assembly	9-48
9.8	UAM0508 – Guide Adjustment Assembly	9-50
9.9	UAM0510 – Drive Unit, Left Hand	9-52

Section	Name	Page
9.10	UAM0511 – Drive Unit, Right Hand	9-54
9.11	WST1036 – Bottom Tape Head Assembly	9-56
9.11.1	WST1023 – Heater Plate Assembly	9-58
9.11.2	WST0059 – Pinch Roller Assembly	9-59
9.11.3	WST0058 – Bottom Knife Arm Assembly	9-60
9.11.4	WST1025 – Pinch Roller Cylinder Assembly	9-61
9.11.5	WST0057 – Solenoid Assembly	9-62
9.11.6	WST1027 – Tape Guide Assembly	9-63
9.11.7	WST1026 – Guide Roller Assembly	9-64
9.11.8	WST1028 – Drivetrain Assembly	9-65
9.11.9	WST1030 – Rear Tucking Arm Assembly	9-66
9.11.10	WST1029 – Front Wipe Down Arm Assembly	9-67
9.11.11	WST1032 – Control Valve Assembly	9-68
9.11.12	WST1022 – Tape Shoe Assembly	9-69
9.11.13	WST1031 – Water Pot Assembly	9-70
9.12	WST1047 – Top Tape Head Assembly	9-71
9.12.1	WST1037 – Left Frame Assembly	9-73
9.12.2	WST1038 – Right Frame Assembly	9-75
9.12.3	WST1023 – Heater Plate Assembly	9-77
9.12.4	WST0059 – Pinch Roller Assembly	9-77
9.12.5	WST0060 – Top Knife Arm Assembly	9-78
9.12.6	WST1025 – Pinch Roller Cylinder Assembly	9-80
9.12.7	WST0057 – Solenoid Assembly	9-80
9.12.8	WST1040 – Top Tape Guide Assembly	9-81
9.12.9	WST1043 – Drivetrain Assembly	9-82
9.12.10	WST1044 – Rear Tucking Arm Assembly	9-83
9.12.11	WST1045 – Front Tucking Arm Assembly	9-84
9.12.12	WST1042 – Pneumatic Assembly	9-85
9.12.13	WST1039 – Tape Shoe Assembly	9-86
9.12.14	WST1031 – Water Pot Assembly	9-87
9.12.15	WST1035 – Cover with Handle	9-88

This page is intentionally blank.


9.1 UM805T - USA2024-WAT-EU TOP LEVEL ASSEMBLY



USM0868 - USA2024-WAT-EU CASE SEALER

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UAM0512	BRIDGE ASSEMBLY	1
2	UAM0487	COLUMN ASSEMBLY, R.H.	1
3	UAM0511	DRIVE UNIT, R.H	1
4	USM0867	BASE ASSEMBLY	1
5	WST1036	BOTTOM TAPE HEAD	1
6	UAM0510	DRIVE UNIT, L.H	1
7	UAM0508	GUIDE ADJUSTMENT ASSEMBLY	1
8	UPM5987	COLUMN ASSEMBLY, ADJUSTABLE, L.H.	1
9	UAM0488	CONTROL BOX	1
10	UAM0489	OUTPUT TABLE	1
11	WST1047	TOP TAPE HEAD	1


9.2 UAM0512 - BRIDGE ASSEMBLY



UAM0512 - BRIDGE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF3169	SHCS M5-0.8 x 16mm	3
2	UF7021	LW M5	3
3	UF1827	M5 FW	3
4	UPM6166	BRACKET	1
5	USM0907	TOP T.H. WATER BOTTLE ASS'Y	1
6	UPM2192	BLACK PLUG	4
7	UPM1011	BRIDGE COVER PLATE SLOTTED	1
8	UAM0513	BRIDGE BASE ASSEMBLY	1
9	USM0823	COMPRESSION GUIDE ASS'Y R.H.	1
10	USM0391	SINGLE LOCK.ASS'Y	1
11	UAM0471	COMPRESSION GUIDE ASS'Y L.H.	1
12	UF3680	M10 FW	8
13	UF3743	LW M10	8
14	UF4310	BHCS M10-1.5×30L	8
15	UPM1008	BRIDGE PLATE COVER	1
16	UF1828	M6 FW	4
17	UF6363	LW M6	4
18	UF3179	SHCS M6-1.0×20L	4
19	USM7585	TOP TAPE CARRIAGE ASSEMBLY	1


9.2.1 UAM0513 – Bridge Base Assembly



UAM0513 - BRIDGE BASE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5733	E-STOP	1
2	UPM6045	E-STOP LABEL	1
3	UF3685	BHCS M4-0.7×8L	4
4	UF3749	LW M4	10
5	UF3710	M4 FW	6
6	UPM6167	E-STOP PLATE	1
7	UPM5967	GUIDE ROLLER, 40OD	6
8	WET0241	CORD GRIP	1
9	UPM6165	BRIDGE WELDMENT	1
10	UPM6146	10.9MM GROMET	2
11	UF3691	Pop Rivet 4mm	4
12	UPM5091	USA UHMW STRIP	2
13	UF0074	FHCS M5-0.8×50L	2
14	UPM4968	BRUSH HOLDER ADAPTER	1
15	UPH4004	BRUSH 4" TH	1
16	UF3714	FHCS M4-0.7×12L	4
17	UPM4980	ELECTRICAL RECEPTACLE BASE	1
18	UPM4938	RECEPTACLE CONNECTION	1
19	UF5404	FHCS M5-0.8×16L	2
20	UPM5102	SHAFT, dia 9.5	1
21	UPM4991	SHAFT, dia 9.5, 181L	1
22	UF7003	SHCS M5-0.8 x 12mm	6
23	UPM4989	TOP COVER	1
24	UPM6145	RETAINING RING S10	4
25	UPM4992	SPACER, 18L	2
26	UPM5137	PHOTOELECTRIC SENSOR	1
27	UF9148	SHCS M4-0.7×10L	6
28	UF1241EV	BHCS M6-1.0×20L	2
29	UPM4993	SHAFT, dia 12.7, 189L	3
30	UPM4933	ROLLER, dia 17, 72L	3
31	UPM4936	RUBBER RING	6
32	UF1828	M6 FW	2
33	UPM4990	OVER FLOW TRAY	1
34	UF6376	LOCK-NUT	2
35	UPM5084	SPRING SUPPORT	2
36	UPM1068	COMPRESSION SPRING	2
37	UF3760	SHCS M4-0.7×50L	2
38	UPM4997	BRACKET	1
39	UF6363	LW M6	2
40	UF1192	FHCS M6-1.0×16L	6


9.2.2 USM0907 – Top Tape Head Water Bottle Assembly



USM0907 - TOP TAPE HEAD WATER BOTTLE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5116	FRAME	1
2	UPM5120	WT BOTTLE HOLDER	2
3	UF3751	SS HHCS M6-1.0 x 16mm	4
4	UF6411	SS LW M6	4
5	UF1890	FLAT WASHER 1/4 x 3/4 x 1/16	4
6	UPM4945	CUP HOLDER	1
7	UPM5165	TUBE, 6 OD x 4 ID	1
8	UPM5148	ELBOW FITTING	1
9	UPH1496	REDUCER	1
10	UPM4946	RESERVOIR CUP	1
11	UPM4947	PLUNGER	1
12	UF7011	SS BHCS M5-0.8 X 12mm	4
13	UF7021	SS LW M5	4
14	UF4071	F. WASHER 6 x 12 x 0.5 SS	4
15	UF3262	SS FHCS M5-0.8 x 10 mm	4
16	WST1014	WT Bottle SA	1


9.2.3 USM0391 – Single Lock Assembly



USM0391 - SINGLE LOCK ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	UPM0688	SINGLE LOCKING HANDLE	1
2	UF1318	M8-1.25-BHCS	3
3	UPM0700	SINGLE LOCKING BLOCK	2
4	UPM0703	SHORT BOX 3/4", 1/2" DR, 12 PT	2
5	UPM0698	FLANGED SCREW 1/2-13 L.H.	1
6	UPM2184	COMPRESION SPRING	2
7	UPM2187	SQUARE BAR 0.50"	1
8	UPM0699	FLANGED SCREW 1/2-13 R.H.	1


9.2.4 UAM0471 – Compression Guide Assembly, Left Hand



UAM0471 - COMPRESSION GUIDE ASSEMBLY, LEFT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UAM0376	KNOB CW 5mm PIN-SS	1
2	UPM7538	GUIDE BLOCK TOP	1
3	UPM3285EV	GUIDE BLOCK	1
4	UPM9740	WHEEL GUIDE SPACER	1
5	UF3819	FHCS M6 - 1 x 90	4
6	UPM6482	ROLLER GUIDE 2 7/8" DIA BLACK	3
7	UF3024	SS HHCS 3/8-16 x 1.75	3
8	UPM5132	WHEEL SUPPORT PLATE	1


9.2.5 USM0823 – Compression Guide Assembly, Right Hand



USM0823 - COMPRESSION GUIDE ASSEMBLY, RIGHT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UAM0376	KNOB CW 5mm PIN-SS	1
2	UPM9740	WHEEL GUIDE SPACER	1
3	UPM9740	WHEEL SUPPORT PLATE	1
4	UF3024	SS HHCS 3/8-16 x 1.75	3
5	UPM6482	PLASTIC WHEEL 3\"DIA. WITH BEARING	3
6	UF3819	FHCS M6 - 1 x 90	4
7	UPM3285EV	GUIDE BLOCK	1
8	UPM7538	GUIDE BLOCK TOP	1


9.2.6 USM7585 – Top Tape Carriage Assembly



USM7585 - TOP TAPE CARRIAGE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM4889	HANDLE	1
2	UF3815	RET'G RING, ID 10	1
3	UAM0195	MANDREL HUB	1
4	UPM5111	PANCAKE	1
5	UPM5109	STEPPED SHAFT R.H.	1
6	UF4503	SS BHCS M6-1 x 40mm	1
7	UPM5200	BACK COVER	1
8	UF6339	SS FW M4	3
9	UF3749	SS LW M4	3
10	UF4325	SS BHCS M4-0.7 x 12mm	3
11	UF3816	HEX NUT M24 - 1.5	2
12	UPM9901	HUB USA	1
13	UF3277	SS FHCS M5-0.8 x 16 mm	4
14	UF3361	SS JAM NUT M6	1
15	UPM5201	MANDREL FRAME	1
16	UAM0479	DANCER ARM ASSEMBLY	1
17	UPM5715	CROSS BAR ASSEMBLY	1


9.2.6.1 UAM0479 – Dancer Arm Assembly



UAM0479 - DANCER ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM9802	BREAK PAD	1
2	UPM6238	PIVOT ARM R.H.	1
3	UPM4498	EXTENSION SPRING	1
4	UF0062	M6-1.0-HNR	1
5	UF1241EV	BHCS M6-1.0x20L	3
6	UF6336	F.W. PTFE, 13 x 19 x 1 mm	1
7	UF6363	LW M6	1
8	UPH9059	PEEL OFF ROLLER ET 72	1
9	UPH0949	GUIDE ROLLER SHAFT	1
10	UF3680	M10 FW	1

9.2.6.2 UAM0195 – Mandrel Hub




UAM0195 - MANDREL HUB

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5074	SPRAG, Mandrel	3
2	UPH1468	COMPRESSION SPRING	6
3	UPM5073	MANDREL HUB	1
4	UPM0324	BEARING PULLEY	2
5	UF0101	INTERNAL RETAINING RING, 42mm	1
6	UF9164	M3-0.5×12L	3
7	UF5404	FHCS M5-0.8×16L	4

This page is intentionally blank.


9.3 UAM0487 - COLUMN ASSEMBLY, RIGHT HAND



UAM0487 - COLUMN ASSEMBLY, RIGHT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF6382	M10-1.5×25L	2
2	UF3743	LW M10	6
3	UF3680	M10 FW	6
4	UPM2182	COLUMN CAP RIGHT SIDE	1
5	UPM2251	SAFETY BUMPER	1
6	UPM4986	LINEAR BEARING 25 mm	2
7	UF5400	FHCS M5-0.8×12L	2
8	UPM6013	COLUMN WELDMENT, R.H.	1
9	UF3647	HHCS M10 X 1.25 X 25	4
10	UPM0738	COLUMN SHAFT USA2024 SB222	1
11	UPM9741	SHAFT COLLAR	1
12	UF1318	BHCS M8-1.25×20L	2
13	UF3640	LW M8	2
14	UPM3740	SPRING ANCHOR RIGHT SIDE	1
15	UF0075	PHS M5-0.8×68L	3
16	UPM0743	SPRING MANDREL SHAFT	3
17	UPM0742	SPRING MANDREL 2"	3
18	UF1211	BHCS M6-1.0×10L	6
19	UPM0740	CONSTANT FORCE SPRING 33LB	3
20	UPE0164	COLUMN BLOCK, RIGHT	1


9.4 UPM5987 - COLUMN ASSEMBLY, ADJUSTABLE, LEFT HAND



UPM5987 - COLUMN ASSEMBLY, ADJUSTABLE, LEFT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF6382	M10-1.5×25L	2
2	UF3743	LW M10	6
3	UF3680	M10 FW	6
4	UPM5992	CAP	1
5	UF1250EV	BHCS M6-1.0×16L	6
6	UF6363	LW M6	11
7	UF1828	M6 FW	6
8	UPM5991	COLUMN MOVING BLOCK	1
9	UPM0740	CONSTANT FORCE SPRING 33LB	3
10	UF1211	BHCS M6-1.0×10L	6
11	UPM0742	SPRING MANDREL 2"	3
12	UPM0743	SPRING MANDREL SHAFT	3
13	UF0075	PHS M5-0.8×68L	3
14	UPM4150	SPRING ANCHOR UA2024	1
15	UF3640	LW M8	2
16	UF1318	BHCS M8-1.25×20L	2
17	UF0835	SHCS M6-1.0×20L	1
18	UPM9741	SHAFT COLLAR	1
19	UPM0738	COLUMN SHAFT USA2024 SB222	1
20	UF3647	HHCS M10 X 1.25 X 25	4
21	UPM5773	KEY 5X5X20	1
22	UF0630EV	SHCS M6-1.0×25L	1
23	UF0103	M6 FW, 19MM OD 2MM THK	1
24	UPE0001	HANDLE, FOLDABLE	1
25	UF3187	SHCS M6-1.0×16L	4
26	UPM5226	CONNECTING BEARING	2
27	UPM5998	COVER	1
28	UF6374	BHCS M4-0.7×6L	2
29	UAM0485	COLUMN WELDMENT	1
30	UF5400	FHCS M5-0.8×12L	2
31	UPM5989	BALL SCREW BLOCK	1
32	UPM5614	BEARING	1
33	UPM5990	BALL SCREW	1
34	UPM4986	LINEAR BEARING 25 mm	2
35	UPM5993	PLATE	1
36	UPM6013	CAP	1


9.5 UAM0488 – CONTROL BOX



UAM0488 - CONTROL BOX

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF0038	SHCS M6-1.0×12L	4
2	UF6363	LW M6	4
3	UF0103	M6 FW, 19MM OD 2MM THK	4
4	UPM6047	PUSH BUTTON, BLUE	1
5	UPM4926	ILLUMINATED PB, MUSHROOM, BLUE	1
6	UPM6169	OPERATION BOX	1
7	UPM4905	CORD GRIP	1
8	UPM6168	OPERATION BOX COVER	1
9	UF0069	BHCS M4-0.7×25L	6
10	UPM6051	PUSH BUTTON, RED	1
11	UPM5734	START SWITCH	2
12	UPM5733	E-STOP	1
13	UPM6050	3 POS SELECTOR SWITCH	1
14	UPM5709	PUSH BUTTON	2
15	UPM6048	ILLUMINATED PILOT LIGHT	1
16	UPM6049	2 POS SELECTOR SWITCH	1


9.6 UAM0489 – OUTPUT TABLE



UAM0489 - OUTPUT TABLE

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5733	E-STOP	1
2	UPM6045	E-STOP LABEL	1
3	UF0864	SHCS M8-1.25×20L	4
4	UF3640	LW M8	4
5	UF0105	M8 FW	4
6	UPM6039	TAPE ROLL CARRIAGE	1
7	UAM0506	BTM TAPE CARRIAGE	1
8	UPM0847	LEG ADJUSTMENT WELDMENT FOR USA2024 REDESIGN	2
9	UPM0931	LEG FRICTION PLATE	2
10	UF3734	HHCS M12-1.75×35L	4
11	UF4231	M12 FW	4
12	UPM5142	LEG WELDMENT	1
13	UF4230	LW M12	4
14	UAM0504	OUTPUT TABLE TOP	1
15	UPM5141	LEG WELDMENT	1
16	UPM6044	E-STOP BRACKET	1
17	UF3710	M4 FW	2
18	UF3749	LW M4	2
19	UF4312	SHCS M4-0.7×6L	2
20	UPM6170	BUTTON BOX	1


9.6.1 UAM0504 – Output Table Top



UAM0504 - OUTPUT TABLE TOP

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF1318	BHCS M8-1.25×20L	20
2	UPM5222	CHAIN SHIELD	1
3	UPM4969	CHAIN COVER	1
4	UF5601	BHCS M5-0.8×6L	15
5	UPM4891	CHAIN #40, 12 PITCH	8
6	UPM4890	CHAIN #40, 25 PITCH	1
7	UAM0505	OUTPUT TABLE WELDMENT	1
8	UPM5124	CHAIN COVER	1
9	UF6340	SS FW M5	4
10	UF7023	LW 5MM	8
11	UF3776	SS SHCS M5 x 0.8 x 40mm	4
12	UPM5711	SWITCH SNAP ACTION SPDT 10A 125V	1
13	UPM6037	POST	4
14	UF3687	BHCS M5-0.8×12L	4
15	UPM6038	BOTTOM COVER	1
16	UPM5126	SPROCKET	1
17	UF0038	SHCS M6-1.0×12L	4
18	UF6341	SS FW M6	8
19	UPM5885	MOTOR	1
20	UF3391	SS NYLON LOCK NUT M6-1.0	4
21	UF3750	SS SSS M6 X 10mm	2
22	UF3680	FW M10	8
23	UF4252	BHCS M10-1.5×20L	8
24	UF6371	M10 LW	8
25	UF0867	LW M8	20
26	UF1821	FW M8	20
27	UF7009	SS BHCS M4-0.7 x 8	3
28	UPM5125	ROLLER	10
29	UF3681	LW M4	3
30	UF3710	FW M4	3


9.6.2 UAM0506 – BTM Tape Carriage



UAM0506 - BTM TAPE CARRIAGE

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF0091	FHCS M8-1.25×25L	4
2	UF3640	LW M8	4
3	UF6369	M8-1.25-HNR	4
4	UF3816	M24-1.5-HNR	1
5	UF5399	FHCS M5-0.8×25L	4
6	UPM5114	HUB	1
7	UPM6143	BACK FRAME	1
8	UPM5109	STEPPED SHAFT R.H.	1
9	UF3815	RET'G RING, ID 10	1
10	UAM0481	DANCER ARM ASSEMBLY	1
11	UPM5111	PANCAKE	1
12	UAM0195	MANDREL HUB	1
13	UPM5715	CROSS BAR ASSEMBLY	1
14	UPM4889	HANDLE	1


9.6.3 UPM6039 –Tape Roll Carriage



UPM6039 - TAPE ROLL CARRIAGE

ITEM	PART#	DESCRIPTION	QTY.
1	UPM6042	BRACKET	1
2	UF1250EV	BHCS M6-1.0×16L	4
3	UF6363	LW M6	7
4	UF1828	M6 FW	7
5	UF0098	SHCS M8-1.25×25L	8
6	UF3640	LW M8	8
7	UF0105	M8 FW	8
8	UPM6142	SHUTTLE BLOCK	2
9	UPM6043	SHAFT	2
10	UF3680	M10 FW	4
11	UF3743	LW M10	4
12	UF3679	HHCS M10-1.5×20L	4
13	UPM6040	BRACKET	1
14	UPM5713	SHAFT COLLAR	2
15	UPM2539	BUSHING	1
16	UF0108	FW, 16 OD, 10.5 ID, 0.5 THK	1
17	UPM2803	ROTARY SLEEVE	1
18	UF7021	LW M5	1
19	UF0037	BHCS M5-0.8×16L	1
20	UF0106	M5 FW	1
21	UPM2784	HANDLE	1
22	UF0057	INTERNAL TOOTH LW M10	1
23	UF0107	HEX JAM NUT, M10 x 1.5	1
24	UPM2792	DIVIDE POSITIONING PILLAR	1
25	UPM2471	DRAG LINK	1
26	UPM6041	BAR	1
27	UF0835	SHCS M6-1.0×20L	5


9.7 USM0867 – BASE ASSEMBLY



USM0867 - BASE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5986	SIDE COVER, R.H.	1
2	UAM0503	ELECTRICAL BOX	1
3	UAM0473	INLET TABLE ASSEMBLY	1
4	UAM0483	INLET STOP ASSEMBLY	1
5	UAM0485	PNEUMATIC ASSEMBLY	1
6	UAM0468	FRAME ASSEMBLY	1
7	UAM0482	LOWER HOST BASE ASSEMBLY	1
8	USM0901	WATER BOTTLE UNIT ASS'Y	1
9	UPM3226	PVC ROL CHARCOAL DIA 1.9 X 12.00	14
10	UF3170	SHCS M6-1.0×8L	4
11	UPM5985	SIDE COVER, L.H.	1
12	UAM0474	ROLLER ASSEMBLY, L.H.	1
13	UAM0478	OUTLET TABLE ASSEMBLY	1
14	UAM0477	ROLLER ASSEMBLY, R.H.	1


9.7.1 UAM0485 –Pneumatic Assembly



UAM0485 - PNEUMATIC ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM3391	SILENCER VALVE	2
2	UF3710	M4 FW	6
3	UF6376	LOCK-NUT	2
4	UPM5979	ELECTRIC CONTROL CONNECTOR	1
5	UPM5984	90° QUICK CONNECTOR	1
6	UPM5978	ON-OFF VALVE	1
7	UF1827	M5 FW	2
8	UF7021	LW M5	2
9	UF3686	BHCS M5-0.8×10L	2
10	UPM5975	COIL CONNECTOR COVER	1
11	UPM6171	SILENCER	1
12	UPM5983	CONNECTOR, STRAIGHT	1
13	UF3694	SHCS M4-0.7×80L	2
14	UPM5977	REGULATOR	1
15	UPM5982	90° ELBOW	1
16	UPM5976	SPACER	1
17	UF3749	LW M4	2
18	UF4237	M4-0.7-HNR	2
19	UPM5981	WIRE CONNECTOR	1
20	UPM5980	SOLENOID VALVE	1
21	UF3649	BHCS M4-0.7×12L	2
22	UPM6172	RAIL	1

9.7.2 UAM0503 – Electrical Box




UAM0503 - ELECTRICAL BOX

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF0099	SHCS M8-1.25x30L	4
2	UF3640	LW M8	4
3	UF0113	M8 FW	8
4	UPM6177	HMI, SCREEN	1
5	UPM6174	ELEC. CAB. MOUNT BAR	2
6	UPM6173	ELECTRICAL CABINET	1
7	UPM6175	ELEC. CAB. COVER	1
8	UF1827	M5 FW	5
9	UF7021	LW M5	5
10	UF7003	SHCS M5-0.8 x 12mm	5
11	UPM6176	ELEC. CAB. GROUND BLOCK	1
12	UPM6242	WIRE WAY 33mm, 545L	1

ITEM	PART NUMBER	DESCRIPTION	QTY.
13	UPM6239	WIRE WAY 33mm, 305L	1
14	UPM6244	COVER 33mm, 305L	1
15	UPM6243	WIRE WAY 33mm, 555L	1
16	UPM6248	COVER 33mm, 555L	1
17	UPM6250	RAIL, 555L	1
18	UPM6240	WIRE WAY 33mm, 520L	1
19	UPM7440EV	DIN RAIL ANCHOR	4
20	UPM4922	RELAY	6
21	UPM6245	COVER 33mm, 520L	1
22	UPM6241	WIRE WAY 33mm, 280L	1
23	UPM6246	COVER 33mm, 280L	1
24	UPM6195	END COVER	5
25	UPM6193	DOUBLE LEVEL TERMINAL BLOCK, 1	45
26	UPM6198	5 PIN BRIDGE	2
27	UPM6199	10 PIN BRIDGE	2
28	UPM6197	2 PIN BRIDGE	2
29	UPM6194	TERMINAL BLOCK, GROUND, 1	5
30	UPM6193	TERMINAL BLOCK, 1	2
31	UPM6196	END COVER	1
32	UPM6188	ELECTROMAGNETIC CONTACTOR (DC24V)	1
33	UPM6190	AC120 RELAY, MECHANICAL INDICATOR	1
34	UPM6191	RELAY SOCKET, DIN RAIL, 8 PIN	1
35	UPM6179	LOOP PROTECTOR, 7A	1
36	UPM6180	LOOP PROTECTOR, 3A	1
37	UPM6182	LOOP PROTECTOR, 3A, 2100	1
38	UPM6181	LOOP PROTECTOR, 2A, 2100	2
39	UPM4909	PLC 24 INPUT / 16 OUTPUT	1
40	UPM6183	PLC EXPANSION MODULE	1
41	UPM6184	PLC EXPANSION MODULE	1
42	UPM6247	COVER 33mm, 545L	1
43	UPM4907	PLC ANALOG I/O CONTROL CARD	1
44	UPM6251	RAIL, 508L	1
45	UPM6178	POWER SWITCH	1
46	UPM6172	RAIL, 90L	2
47	UF4312	SHCS M4-0.7×6L	4
48	UF3749	LW M4	4
49	UF3710	M4 FW	4
50	UF0063	LOCK-NUT	4
51	UPM6185	TRANSFORMER	1
52	UPM6186	FILTER	1
53	UPM4912	POWER SUPPLY 240W	1
54	UPM6187	SAFETY MODULE	1
55	UPM6249	RAIL, 160L	1
56	UPM6189	ELECTROMAGNETIC CONTACTOR (AC110V)	3
57	UPM4914	MOTOR OVERLOAD RELAYS	3


9.7.3 UAM0483 – Inlet Stop Assembly



UAM0483 - INLET STOP ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF3264	FHCS M8-1.25x20L	4
2	UPM7513	STOP	1
3	UPM5972	CYLINDER W/ GUIDE ROD	1
4	UPM5974	PLUG, G1/8	2
5	UPM5973	FLOW CONTROL, 1/8	2
6	UPM5971	STOP BRACKET	1
7	UF0103	M6 FW, 19MM OD 2MM THK	4
8	UF6363	LW M6	4
9	UF5600	BHCS M6-1.0x12L	4
10	UF3640	LW M8	4
11	UF6309	HHCS M8-1.25x20L	4


9.7.4 UAM0482 – Lower Host Base Assembly



UAM0482 - LOWER HOST BASE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF4252	BHCS M10-1.5x20L	8
2	UF3743	LW M10	8
3	UF3680	M10 FW	8
4	UF1828	M6 FW	8
5	UF3187	SHCS M6-1.0x16L	8
6	UPM6148	LOWER HOST BASE, R.H.	1
7	UF6363	LW M6	8
8	UPM5970	LOWER HOST COVER	1
9	UF1827	M5 FW	6
10	UF3686	BHCS M5-0.8x10L	6
11	UF7021	LW M5	6
12	UPM6252	SHAFT, 140L	4
13	UPM6147	LOWER HOST BASE, L.H.	1
14	UF7009	M4-0.7-SS BHCS	3
15	UF3749	M4 SS LW	3
16	UPM6253	LOWER DRAIN TRAY	1


9.7.5 USM0901 – Water Bottle Unit Assembly



USM0901 - WATER BOTTLE UNIT ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WST1014	WT Bottle SA	1
2	UPM4943	FRAME	1
3	UPM4945	CUP HOLDER	1
4	UF6339	SS FW M4	4
5	UF3749	SS LW M4	4
6	UF6364	SS BHCS M4 x 0.7 x 10mm	4
7	UPM4947	PLUNGER	1
8	UPM4946	RESERVOIR CUP	1
9	UPH1496	REDUCER	1
10	UPM5148	ELBOW FITTING	1
11	UPM5165	TUBE, 6 OD x 4 ID	1
12	UF6341	SS FW M6	4
13	UF3751	SS HHCS M6-1.0 x 16mm	4
14	UF6411	SS LW M6	4
15	UPM4944	HOLDER BRACKET	1
16	UF3262	SS FHCS M5-0.8 x 10 mm	4


9.7.6 UAM0478 – Outlet Table Assembly



UAM0478 - OUTLET TABLE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF0075	M5-0.8-SELF TAPPING	6
2	UPM5962	SLIP PAD, R.H.	1
3	UF6305	FHCS M5-0.8×10L	6
4	UPM5964	COVER	1
5	UPM5965	BRUSH	1
6	UF1827	M5 FW	10
7	UF0039	SHCS M5-0.8 x 10mm	6
8	UF7021	LW M5	10
9	UF7003	SHCS M5-0.8 x 12mm	4
10	UPM5960	REAR SUPPORT SEAT, R.H.	1
11	UPM6254	SHIM 0.1mm	4
12	UPM5953	SHIM 1.0mm	4
13	UPM6265	SHIM 0.5mm	4
14	UPM6255	SHIM 0.2mm	8
15	UPM5959	REAR SUPPORT SEAT, L.H.	1
16	UF1828	M6 FW	2
17	UF6363	LW M6	4
18	UF0038	SHCS M6-1.0×12L	4
19	UF3687	BHCS M5-0.8×12L	4
20	UPM5967	GUIDE ROLLER, 40OD	4
21	UF5923	O RING	4
22	UPM5968	SHAFT, 115L, GROOVED	2
23	UPM5966	ROLLER, dia 17, 72L, WHITE	2
24	UPM5963	SENSOR BRACKET	1
25	UPM5969	PHOTOELECTRIC SENSOR	1
26	UPM5961	SLIP PAD, L.H.	1


9.7.7 UAM0477 – Roller Assembly, Right Hand



UAM0477 - ROLLER ASSEMBLY, RIGHT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM4942	ROLLER SHAFT	5
2	UPM4941	ROLLER	10
3	UF3710	M4 FW	10
4	UF9148	SHCS M4-0.7×10L	10
5	UF3749	LW M4	10
6	UF0039	SHCS M5-0.8 x 10mm	2
7	UPM5958	ROLLER PLATE	1
8	UF3170	SHCS M6-1.0×8L	2
9	UF1827	M5 FW	2
10	UF3393	LOCK-NUT, M5	2


9.7.8 UAM0474 – Roller Assembly, Left Hand



UAM0474 - ROLLER ASSEMBLY, LEFT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF3710	M4 FW	10
2	UF3749	LW M4	10
3	UF9148	SHCS M4-0.7×10L	10
4	UPM4941	ROLLER	10
5	UPM4942	ROLLER SHAFT	5
6	UF3393	LOCK-NUT	2
7	UF1827	M5 FW	2
8	UF3170	SHCS M6-1.0×8L	2
9	UF0039	SHCS M5-0.8 x 10mm	2
10	UPM5957	ROLLER PLATE	1


9.7.9 UAM0473 – Inlet Table Assembly



UAM0473 - INLET TABLE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF1827	M5 FW	12
2	UF7021	LW M5	12
3	UF0039	SHCS M5-0.8 x 10mm	12
4	UPM5956	SENSOR SUPPORT	1
5	UPM0317	SENSOR	2
6	UPM5952	FRONT SEAT, R.H.	1
7	UF7003	SHCS M5-0.8 x 12mm	8
8	UPM5955	SENSOR SUPPORT	1
9	UPM6254	SHIM 0.1mm	4
10	UPM6255	SHIM 0.2mm	8
11	UPM6265	SHIM 0.5mm	4
12	UPM5953	SHIM 1.0mm	4
13	UPM5951	FRONT SEAT, L.H.	1
14	UPM4954	SLIDING PAD	2
15	UF0075	M5-0.8-SELF TAPPING	10
16	UPM5954	COVER PLATE	1


9.7.10 UAM0468 – Frame Assembly



UAM0468 - FRAME ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM5950	CORD SLEEVE	1
2	UPM6267	WIRING BOX	2
3	UF6307	HEX NUT M5-0.8	6
4	UF7023	LW 5MM	12
5	UF6340	SS FW M5	12
6	UPM5949	CYLINDER HEAD	1
7	UPM4987	CORD SLEEVE ELBOW	1
8	UPM5940	BASE WELDMENT	1
9	UPM0602	LEG WELDMENT	4
10	UPM5948	BASE FRONT COVER	1
11	UF5601	BHCS M5-0.8×6L	12
12	UF3687	BHCS M5-0.8×12L	4
13	UF3734	SS HHCS M12-1.75 x 35mm	8
14	UF3733	SS LW M12	8
15	UPM0847	LEG ADJUSTMENT WELDMENT FOR USA2024 REDESIGN	4
16	UPM0931	LEG FRICTION PLATE	4
17	UF6343	SS FW M12	8
18	UF3680	FW M10	24
19	UF6371	M10 LW	24
20	UF1540	HNR 3/8-16	24
21	UPM4939	ELECTRICAL RECEPTACLE CONNECTION MALE	1
22	UF3759	SS SHCS M4-0.7 x 10mm	4
23	WET0241	CORD GRIP	2
24	UF3681	LW M4	4
25	UPM4929	ELECTRICAL RECEPTACLE BASE	1
26	UPM4938	RECEPTACLE CONNECTION	1
27	UF3187	SHCS M6-1.0×16L	2
28	UF6411	SS LW M6	2
29	UF6341	SS FW M6	2
30	UPM4936	RUBBER RING	2
31	UPM5966	ROLLER, dia 17, 72L, BLACK	1
32	UPM6228	SHAFT, L115, GROOVED	1
33	UPM5967	GUIDE ROLLER, 40OD	2
34	UF0079	SHCS M6-1.0×6L	8
35	UPM5945	REAR BEAM	1
36	UF3148	M5-0.8 x 16 SHCS	2
37	UPM5944	FRONT BEAM	1

9.8 UAM0508 – GUIDE ADJUSTMENT ASSEMBLY




UAM0508 - GUIDE ADJUSTMENT ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM6269	SHAFT 888.6mm L	2
2	UAM0509	FLOATING SUPPORT	1
3	UPM3330	SHAFT COLLAR, 20mm	4
4	UF6369	M8-1.25-HNR	12
5	UF3640	LW M8	12
6	UPM6079	SHAFT ANCHOR PLATE, SS	4
7	UF3179	SHCS M6-1.0x20L	7
8	UF6363	LW M6	21
9	UF0114	M12-1.75-HHCS	1
10	UPM6153	BRACKET	1
11	UF1828	M6 FW	4

ITEM	PART NUMBER	DESCRIPTION	QTY.
12	UPM6270	CAP	1
13	UPM6268	BRING SPCR ALU. 2.00ID X .125THK	1
14	UPM0523	FLANGE BEARING	2
15	UPM6156	SHAFT COLLAR, ONE PIECE	2
16	UPM6272	GUIDE BLOCK	1
17	UPM6152	ADJUSTMENT SHAFT	1
18	UPM5773	KEY 5x5-20	5
19	UF5925	M5-0.8 10L SET SCREW	8
20	UPM0150	SPROCKET SHAFT WASHER	4
21	UF3816	M24-1.5-HNR	2
22	UPM0054	SPRING 1-17/64 OD X 1-5/8 LG X .148	1
23	UF0053	M24 FW	1
24	UF3169	SHCS M5-0.8 x 16mm	4
25	UF7021	LW M5	4
26	UPM6160	SPRING PLATE	1
27	UF2231	SHAFT COLLAR, SET SCR, 3/4" BORE	1
28	UPM6159	STANDOFF	2
29	UPE0001	HANDLE, FOLDABLE	1
30	UF0103	M6 FW, 19MM OD 2MM THK	1
31	UF5400	FHCS M5-0.8x12L	8
32	UPM6157	BEARING SPACER	1
33	UF3187	SHCS M6-1.0x16L	4
34	UPM6161	FIBER WASHER	1
35	UPM0028	SPROCKET	4
36	UPM1646	SPROCKET SHAFT SPACER (LONG)	4
37	UPM1637	BEARING R8-2RS	4
38	UPM3262	SPROCKET SHAFT BEARING HOUSING RH	2
39	UAM0141	DRIVE SUPPORT RSA 2024	1
40	M12-1.75	LOCK-NUT	1
41	UPM6158	SEAL	1
42	UPM6154	SPRING SHAFT	2
43	UPM6155	SPRING	1
44	UPM3275	SPROCKET SHAFT BEARING HOUSING LH	2
45	UF4231	M12 FW	4
46	UF4230	LW M12	4
47	UF0061	HHCS M12-1.75x20L	4
48	UPM6272	CHAIN #35	4
49	UPM3260	CHAIN THREADED LINK RH	4
50	UF0062	M6-1.0-HNR	16
51	UPM3255	TURNBUCKLE	4
52	UPM1168	CHAIN THREADED LINK LH	4
53	UPM3316	SHAFT 20MM CG RSA 2024	2
54	UAM0516	DRIVE SUPPORT RSA 2024 MODIFIED	2


9.9 UAM0510 – DRIVE UNIT, LEFT HAND



UAM0510 - DRIVE UNIT, LEFT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM4975	COVER LEFT SIDE	1
2	UPM7468	DRIVING BELT 50 x 2360L	1
3	UPM4883	DRIVE PULLEY	1
4	UF3683	M6-1.0-SSS	2
5	UF3752	BHCS M6-1.0×30L	3
6	UF3712	FHCS M6-1.0×30L	1
7	UPM6163	DRIVE WELDMENT, L.H	1
8	UPM4008	MOTOR 1/3HP 25:1 NEMA4	1
9	UF0103	M6 FW, 19MM OD 2MM THK	6
10	UF5900	LOCK-NUT M6	4
11	UPM4974	BELT PAD	2
12	UF3169	SHCS M5-0.8 x 16mm	8
13	UF3393	LOCK-NUT	8
14	UF1827	M5 FW	8
15	UF1192	FHCS M6-1.0×16L	2
16	UF3748	M10-1.5-FHCS	1
17	UPM2156	TENSIONER ALIGNMENT PLATE	1
18	UF1411	M6-1.0-SSS	1
19	UPM0647	CARTON RETAINER	1
20	UF6363	LW M6	2
21	UF0454	M6-1.0-HHCS	2
22	UPM0324	BEARING PULLEY	2
23	UPM1233EV	IDLER PULLEY SHAFT 50mm	1
24	UPM4885	IDLER PULLEY	1
25	UPM0109	IDLER PULLEY SPACER	1
26	UF0017	Ø12MM SNAP RING	1
27	UF5600	BHCS M6-1.0×12L	2
28	UPM0101	TENSIONER BACKING PLATE	1
29	UPM0112	SPRING LOCATOR PIN	1
30	UPM0038	DIE SPRING (DRIVE BASE)	1
31	UF1400	SSS HK 3/8-16 X 3"	1
32	UF3377	3/8"-16-HNR	3


9.10 UAM0511 – DRIVE UNIT, RIGHT HAND



UAM0511 - DRIVE UNIT, RIGHT HAND

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM4973	COVER RIGHT SIDE	1
2	UF5600	BHCS M6-1.0×12L	2
3	UPM7468	DRIVING BELT 50 x 2360L	1
4	UF0017	Ø12MM SNAP RING	1
5	UPM0324	BEARING PULLEY	2
6	UPM0109	IDLER PULLEY SPACER	1
7	UPM4885	IDLER PULLEY	1
8	UPM1233EV	IDLER PULLEY SHAFT 50mm	1
9	UF0103	M6 FW, 19MM OD 2MM THK	6
10	UF6363	LW M6	2
11	UF0454	M6-1.0-HHCS	2
12	UPM0647	CARTON RETAINER	1
13	UPM2156	TENSIONER ALIGNMENT PLATE	1
14	UF3748	M10-1.5-FHCS	1
15	UF1192	FHCS M6-1.0×16L	2
16	UPM4974	BELT PAD	2
17	UF1411	M6-1.0-SSS	1
18	UF1827	M5 FW	8
19	UF3169	SHCS M5-0.8 x 16mm	8
20	UF3393	LOCK-NUT	8
21	UPM4008	MOTOR 1/3HP 25:1 NEMA4	1
22	UF5900	LOCK-NUT M6	4
23	UPM6164	DRIVE WELDMENT, R.H	1
24	UF3712	FHCS M6-1.0×30L	1
25	UF3752	BHCS M6-1.0×30L	3
26	UF3683	M6-1.0-SSS	2
27	UPM4883	DRIVE PULLEY	1
28	UF3377	3/8"-16-HNR	3
29	UF1400	SSS HK 3/8-16 X 3"	1
30	UPM0038	DIE SPRING (DRIVE BASE)	1
31	UPM5759	DOWEL Ø9.5MM X 38MM LG	1
32	UPM0101	TENSIONER BACKING PLATE	1


9.11 WST1036 – BOTTOM TAPE HEAD ASSEMBLY



WST1036 - BOTTOM TAPE HEAD ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WST1028	DRIVETRAIN ASS'Y	1
2	WST1021	RIGHT FRAME ASS'Y	1
3	WET0165	COVER BELT	1
4	UF6339	SS FW M4	3
5	UF7009	SS BHCS M4-0.7 x 8	3
6	UF3749	SS LW M4	3
7	WST1030	REAR TUCKING ARM ASS'Y	1
8	WST0058	BOTTOM KNIFE ARM ASS'Y	1
9	WST1027	TAPE GUIDE ASS'Y	1
10	WST1022	TAPE SHOE ASS'Y	1
11	WST0057	SOLENOID ASS'Y	1
12	WST1023	HEATER PLATE ASS'Y	1
13	WST1031	WATER POT ASS'Y	1
14	UPM6231	CORD	1
15	UPM4905	CORD GRIP	1
16	UPM4939	ELECTRICAL RECEPTACLE CONNECTION MALE	1
17	WET0241	CORD GRIP	1
18	WST1025 TOP HEAD	PINCH ROLLER CYLINDER ASS'Y	1
19	WST1032	CONTROL VALVE ASS'Y	1
20	WST1020	LEFT FRAME ASS'Y	1
21	UPM3583	TUBE 4mm BLUE, SOFT	1
22	WST1026	GUIDE ROLLER ASS'Y	1
23	WST0059	PINCH ROLLER ASS'Y	1
24	WST1029	FRONT WIPE DOWN ARM ASS'Y	1


9.11.1 WST1023 – Heater Plate Assembly



WST1023 – HEATER PLATE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0148	WATER RESERVOIR SUPPORT	1
2	WET0186	HEATER PAD	1
3	WET0185	THERMOSTAT	1
4	UF3717	SS HEX NUT M3-0.5	2
5	UF6350	SS FHCS M3-0.5 x 8 mm	2


9.11.2 WST0059 – Pinch Roller Assembly



WST0059 - PINCH ROLLER ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF7019	SS E RET'G RING EXTERNAL, 10 mm	4
2	UF6389	NYLON FW10.5 x16 x 0.5	2
3	WST0009	WT PINCH ROLLER SA	1
4	WET0149	SHAFT, dia 10mm	1


9.11.3 WST0058 – Bottom Knife Arm Assembly



WST0058 - BOTTOM KNIFE ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WPT0048	WT KNIFE ARM PIVOT SHAFT	3
2	WPT0004	OILITE FLANGE BEARING 10mm	2
3	WPT0075	KNIFE ARM RIGHT FRAME	1
4	UF3761	SS FHCS M4-0.7 x 12mm	6
5	UF3274	SS FHCS M4-0.7 x 8 mm	7
6	WPT0049	WT Cutter Blade Support	1
7	WPT0050	CUTTER BLADE	1
8	UF3553	SS E RET RING EXTERNAL 4mm	2
9	WPT0078	KNIFE ARM BLOCK	1
10	UF6339	SS FW M4	2
11	UF3749	SS LW M4	2
12	UF3759	SS SHCS M4-0.7 x 10mm	2
13	WPT0104	WT KNIFE ARM SUPPORT	1
14	WPT0079	KNIFE ARM BLOCK SHAFT	1
15	UF2215	SHOULDER SCREW M5 x 15L SHOULDER	2
16	WPT0076	KNIFE ARM LEFT FRAME	1
17	WPT0053	EXTENSION SPRING 14.75 COILS	1


9.11.4 WST1025 – Pinch Roller Cylinder Assembly



WST1025 - PINCH ROLLER CYLINDER ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPM4493	8OD x 5ID x 6 BUSHING	1
2	WET0152	CLEVIS	1
3	WET0151	CYLINDER	1
4	UPH4906	M5 x 4mm STRAIGHT FITTING	2
5	WET0150	CYLINDER SUPPORT	1
6	UF4323	SS BHCS M4 - 0.7 x 20mm	4
7	WET0153	PIVOT ARM	1


9.11.5 WST0057 – Solenoid Assembly



WST0057 - SOLENOID ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0019	MOUNTING PLATE	1
2	WET0026	SOLENOID	1
3	UF3710	FW M4	4
4	UF3681	LW M4	4
5	UF7009	SS BHCS M4-0.7 x 8	4


9.11.6 WST1027 – Tape Guide Assembly



WST1027 - TAPE GUIDE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0190	Upper Guide Plate	1
2	UF6351	SS FHCS M4-0.7 x 6 mm	4
3	WET0154	WT TAPE GUIDE	1
4	WPT0044	STRIKER PLATE	1
5	WET0156	TAPE GUIDE SUPPORT	1
6	UF7030	BRASS WASHER 5.18x12x.28mm THK	2
7	UF3717	SS HEX NUT M3-0.5	4
8	UF4518	SS BHCS M3 - 0.5 x 6	4


9.11.7 WST1026 – Guide Roller Assembly



WST1026 - GUIDE ROLLER ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0188	GUIDE ROLLER, 40OD	2
2	UPM4936	RUBBER RING	2
3	WET0189	ROLLER, dia 17, 72L	1
4	WET0187	SHAFT, 115L	1


9.11.8 WST1028 – Drivetrain Assembly



WST1028 - DRIVETRAIN ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0198	ONE WAY CLUTCH BEARING	2
2	UF6300	Ret'g Ring External 12mm	2
3	WET0196	SHAFT, 140L	1
4	WET0195	DRIVE ROLLER TAPE ASSIST	1
5	WET0183	MOTOR, 2GH 20K	1
6	UF2213	SQUARE KEY, ONE ROUND END	1
7	UF4316	BHCS M8-1.25 x 35mm	1
8	WET0194	SPACER, dia 16,6L	1
9	UPH4919	BALL BEARING, 10ID, 35OD, 11t	1
10	WET0192	SPROCKET GEAR WITH KEY	1
11	UF3643	SS FW M8	3
12	UF3735	SS HNR M8-1.25	1
13	UF4508	SS SSS M4-0.7 x 8	6
14	WET0193	SPROCKET GEAR	2
15	WET0199	DRIVE BELT	1
16	WET0197	GUIDE ROLLER	1


9.11.9 WST1030 – Rear Tucking Arm Assembly



WST1030 - REAR TUCKING ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF3752	SS BHCS M6-1 x 30mm	4
2	WET0202	COLLAR	2
3	WET0201	ROLLER CORE	2
4	WET0005	WIPE ARM ROLLER REAR	1
5	WET0203	SHAFT, dia 10	1
6	WET0157	REAR WIPE ARM	1
7	UF3804	SS SSS M3-0.5 x 12mm	2
8	UPH4904	M5 x 4mm OD, FLOW CONTROL	2
9	UPH4849	ROTARY AIR CYLINDER	1
10	UF2214	ROUND KEY	1


9.11.10 WST1029 – Front Wipe Down Arm Assembly



WST1029 - FRONT WIPE DOWN ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0203	SHAFT, dia 10	1
2	WET0201	ROLLER CORE	2
3	WET0202	COLLAR	2
4	UF6325	M6-1 x 20 BHCS	4
5	WET0158	FRONT WIPE ARM	1
6	UF3804	SS SSS M3-0.5 x 12mm	2
7	UPH4905	M5 x 4mm ELBOW FITTING	2
8	UPH4917	ROTARY AIR CYLINDER	1
9	WET0144	WIPE ARM ROLLER	1


9.11.11 WST1032 – Control Valve Assembly



WST1032 - CONTROL VALVE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPH1503	FEMALE/MALE ELBOW	1
2	UPM8001	PLUG, G/18	3
3	WET0208	MANIFOLD	1
4	UPH4903	FLAT MUFFLER G1/8	4
5	UPH4904	M5 x 4mm OD, FLOW CONTROL	1
6	WET0210	MANIFOLD	1
7	WET0211	PRESSURE REGULATOR	2
8	UPH4905	M5 x 4mm ELBOW FITTING	1
9	WET0209	VALVE	3
10	UF6339	SS FW M4	4
11	UF3758	SS SHCS M4-0.7 x 25mm	4
12	UF3749	SS LW M4	4
13	UPH1504	COUPLING PLUG	1


9.11.12 WST1022 – Tape Shoe Assembly



WST1022 - TAPE SHOE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WST1048	MAIN ASS'Y	1
2	UPH4540	FINGER	1
3	UPH3706	SPRING BLADE	1
4	UF3145	SS SHCS M3-0.5 x 6 mm	2
5	WST1049	HINGE ASS'Y	1
6	UF7010	SS BHCS M5 - 0.8 x 8 mm	2
7	UF6340	SS FW M5	2
8	UF3274	SS FHCS M4-0.7 x 8 mm	4
9	WET0182	TAPE SHOE LOCATOR	2


9.11.13 WST1031 – Water Pot Assembly



WST1031 - WATER POT ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0205	PRESSURE PLATE	1
2	WET0167	TAPE GUIDE ENTERANCE	1
3	WET0206	TAPE GUIDE EXIT	1
4	WET0207	SHAFT, 6mm	1
5	UF3804	M3-0.5 X 8mm SSS	2
6	UF3759	SS SHCS M4-0.7 x 10mm	4
7	UF3710	FW M4	4
8	WET0204	WATER POT	1
9	UF3274	SS FHCS M4-0.7 x 8 mm	6
10	UPH1496	REDUCER	1
11	X3117	BALL VALVE	1
12	UPH1500	QUICK COUPLING PLUG	1
13	UPH4921	FEMALE DISCONNECT COUPLING	1
14	UPH1499	REDUCER	1
15	UPH1498	ELBOW FITTING	1
16	WET0071	ROLLER	1


9.12 WST1047 – TOP TAPE HEAD ASSEMBLY



WST1047 - TOP TAPE HEAD ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WST1039	TAPE SHOE ASS'Y	1
2	WST0059	PINCH ROLLER ASS'Y	1
3	WST1045	FRONT TUCKING ARM ASS'Y	1
4	WST1044	REAR TUCKING ARM ASS'Y	1
5	WET0221	TOP COVER	1
6	WST1038	RIGHT FRAME ASS'Y	1
7	WET0213	COVER BELT	1
8	UF3276	SS BHCS M5-0.8 x 6	6
9	WST1046	WATER POT ASS'Y	1
10	WST0060	TOP KNIFE ARM ASS'Y	1
11	WST0057	SOLENOID ASS'Y	1
12	WST1040	TOP TAPE GUIDE ASS'Y	1
13	WST1023	HEATER PLATE ASS'Y	1
14	WST1043	DRIVETRAIN ASS'Y	1
15	WST1025 TOP HEAD	PINCH ROLLER CYLINDER ASS'Y	1
16	WET0212	COVER LEFT SIDE	1
17	UPM4939	ELECTRICAL RECEPTACLE CONNECTION MALE	1
18	UPM4905	CORD GRIP	1
19	UPM6231	CORD	1
20	WET0241	CORD GRIP	1
21	WST1037	LEFT FRAME ASS'Y	1
22	WST1042	PNEUMATIC ASS'Y	1
23	WST1035	COVER WITH HANDLE	1


9.12.1 WST1037 – Left Frame Assembly



WST1037 - LEFT FRAME ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0214	LEFT FRAME PLATE	1
2	UF7009	SS BHCS M4-0.7 x 8	12
3	WET0164	EXTENSION SPRING	1
4	UF3169	SS SHCS M5-0.8 x 16mm	1
5	UF3276	SS BHCS M5-0.8 x 6	2
6	WPT0004	OILITE FLANGE BEARING 10mm	1
7	WET0216	ADAPTOR, 30L	3
8	UF4324	SS NYLON LOCKNUT M4	1
9	UF3274	SS FHCS M4-0.7 x 8 mm	2
10	WET0182	TAPE SHOE LOCATOR	1
11	UF1250	BHCS M6-1 x 16	4
12	UF7007	SS HEX NUT M5-0.8	2
13	UF6340	SS FW M5	2
14	UF3749	SS LW M4	2
15	UF6339	SS FW M4	2
16	UF3183	SS SHCS M6-1 x 12mm	2
17	WET0215	ADAPTOR, 12L	2
18	UF7035	SS BHCS M5-0.8 X 16mm	1
19	WET0217	SHAFT, dia 9.5, 115L	2
20	WET0218	SPACER, 18L	4
21	UF3279	SS BHCS M5-0.8 X 25mm	2
22	UPH4613	KNIFE ARM BUMPER 6"TH	2
23	WET0161	SLEEVE TUBE	2
24	UF3687	BHCS M5-0.8 X 12mm	2
25	UPH0589	REAR SWL BLOCK HOLLOW SHAFT HI	1
26	UPH1501	BALL BEARING 11 x 4 x 4	1
27	UPH1502	SPACER, dia 7.5, 4L	1
28	WET0219	SPACER ROD, dia 20, 115L	1
29	WET0163	SHAFT, dia 12, 115L	3
30	WPT0109	FLANGE BALL BEARING 8 x 19 x 6	2
31	WET0132	WE BEARING HOUSING	2
32	UF6414	SS BHCS M6-1 x 16mm	1

9.12.2 WST1038 – Right Frame Assembly



WST1038 - RIGHT FRAME ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF7007	SS HEX NUT M5-0.8	1
2	WET0182	TAPE SHOE LOCATOR	1
3	UF3274	SS FHCS M4-0.7 x 8 mm	2
4	UF1250	BHCS M6-1 x 16	5
5	WPT0004	OILITE FLANGE BEARING 10mm	1
6	UF7009	SS BHCS M4-0.7 x 8	10
7	WET0216	ADAPTOR, 30L	3
8	UF3183	SS SHCS M6-1 x 12mm	2
9	WET0215	ADAPTOR, 12L	2
10	WET0132	WE BEARING HOUSING	2
11	WPT0109	FLANGE BALL BEARING 8 x 19 x 6	2
12	WET0161	SLEEVE TUBE	2
13	UPH4613	KNIFE ARM BUMPER 6"TH	2
14	UF3279	SS BHCS M5-0.8 X 25mm	1
15	UF6340	SS FW M5	4
16	UF3276	SS BHCS M5-0.8 x 6	6
17	WET0220	RIGHT FRAME PLATE	1
18	WET0222	COVER	1


9.12.3 WST1023 – Heater Plate Assembly - Same as for Bottom Tape Head Assembly.

Refer to [9.11.1 WST1023 – Heater Plate Assembly](#).

9.12.4 WST0059 – Pinch Roller Assembly - Same as for Bottom Tape Head Assembly.

Refer to [9.11.2 WST0059 – Pinch Roller Assembly](#).

9.12.5 WST0060 – Top Knife Arm Assembly



WST0060 - TOP KNIFE ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WPT0004	OILITE FLANGE BEARING 10mm	2
2	WPT0075	KNIFE ARM RIGHT FRAME	1
3	UF2215	SHOULDER SCREW M5 x 15L SHOULDER	2
4	UF3761	SS FHCS M4-0.7 x 12mm	6
5	UF3274	SS FHCS M4-0.7 x 8 mm	7
6	WPT0049	WT Cutter Blade Support	1
7	WPT0048	WT KNIFE ARM PIVOT SHAFT	3
8	WPT0050	CUTTER BLADE	1
9	UF3553	SS E RET RING EXTERNAL 4mm	2
10	WPT0078	KNIFE ARM BLOCK	1
11	WPT0104	WT KNIFE ARM SUPPORT	1
12	UF6339	SS FW M4	2
13	UF3759	SS SHCS M4-0.7 x 10mm	2
14	UF3749	SS LW M4	2
15	WPT0079	KNIFE ARM BLOCK SHAFT	1
16	WPT0076	KNIFE ARM LEFT FRAME	1
17	WPT0053	EXTENSION SPRING 14.75 COILS	1


9.12.6 WST1025 – Pinch Roller Cylinder Assembly - Same as for Bottom Tape Head Assembly.

Refer to [9.11.4 WST1025 – Pinch Roller Cylinder Assembly](#).

9.12.7 WST0057 – Pinch Roller Assembly - Same as for Bottom Tape Head Assembly.

Refer to [9.11.5 WST0057 – Solenoid Assembly](#).


9.12.8 WST1040 – Top Tape Guide Assembly



WST1040 - TOP TAPE GUIDE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0190	Upper Guide Plate	1
2	UF6351	SS FHCS M4-0.7 x 6 mm	4
3	WPT0044	STRIKER PLATE	1
4	WET0156	TAPE GUIDE SUPPORT	1
5	UF7030	BRASS WASHER 5.18x12x.28mm THK	2
6	UF3717	SS HEX NUT M3-0.5	4
7	UF4518	SS BHCS M3 - 0.5 x 6	4
8	WET0237	TAPE GUIDE PLATE	1


9.12.9 WST1043 – Drivetrain Assembly



WST1043 - DRIVETRAIN ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UF3735	SS HNR M8-1.25	1
2	UF3643	SS FW M8	3
3	UPH4919	BALL BEARING, 10ID, 35OD, 11t	1
4	WET0193	SPROCKET GEAR	2
5	WET0229	SPACER, dia 16, 4L	1
6	UF4316	BHCS M8-1.25 x 35mm	1
7	WET0230	MOTOR PLATE	1
8	UF2213	SQUARE KEY, ONE ROUND END	1
9	WET0183	MOTOR, 2GH 20K	1
10	WET0195	DRIVE ROLLER TAPE ASSIST	1
11	WET0196	SHAFT, 140L	1
12	UF7017	SS RET'G RING EXTERNAL 12mm	2
13	WET0198	ONE WAY CLUTCH BEARING	2
14	WET0197	GUIDE ROLLER	1
15	SHSS M4-0.7 x 10	SHSS M4-0.7 x 12	6
16	WET0238	DRIVE BELT	1
17	WET0192	SPROCKET GEAR WITH KEY	1


9.12.10 WST1044 – Rear Tucking Arm Assembly



WST1044 - REAR TUCKING ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0201	ROLLER CORE	2
2	WET0202	COLLAR	2
3	UF1250	BHCS M6-1 x 16	2
4	UF2214	ROUND KEY	1
5	UPH4849	ROTARY AIR CYLINDER	1
6	UF6340	SS FW M5	4
7	UF7021	SS LW M5	4
8	UF7011	SS BHCS M5-0.8 X 12mm	4
9	WET0231	BRACKET	1
10	UF6341	SS FW M6	2
11	UPH4904	M5 x 4mm OD, FLOW CONTROL	2
12	UF3804	SS SSS M3-0.5 x 12mm	2
13	UF4503	SS BHCS M6-1 x 40mm	2
14	WET0239	REAR WIPE DOWN ARM	1
15	WET0005	WIPE ARM ROLLER REAR	1
16	WET0203	SHAFT, dia 10	1


9.12.11 WST1045 – Front Tucking Arm Assembly



WST1045 - FRONT TUCKING ARM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0201	ROLLER CORE	2
2	WET0202	COLLAR	2
3	UF1250	BHCS M6-1 x 16	2
4	UPH4917	ROTARY AIR CYLINDER	1
5	UF7011	SS BHCS M5-0.8 X 12mm	4
6	UF7021	SS LW M5	4
7	UF6340	SS FW M5	6
8	WET0232	BRACKET	1
9	UPH4904	M5 x 4mm OD, FLOW CONTROL	2
10	UF3094	M5-0.8 x 30 BHCS	2
11	WET0240	FRONT WIPE ARM	1
12	UF3804	SS SSS M3-0.5 x 12mm	2
13	WET0203	SHAFT, dia 10	1
14	WET0144	WIPE ARM ROLLER	1


9.12.12 WST1042 – Pneumatic Assembly



WST1042 - PNEUMATIC ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	UPH1504	COUPLING PLUG	1
2	UPH4903	FLAT MUFFLER G1/8	4
3	WET0208	MANIFOLD	1
4	UF3710	FW M4	4
5	UF3749	SS LW M4	4
6	UF4308	SHCS M4-0.7 x 25mm	4
7	WET0209	VALVE	3
8	UPM8001	PLUG, G/18	3
9	WET0228	PLATE	1
10	UPH4905	M5 x 4mm ELBOW FITTING	2
11	WET0210	MANIFOLD	1
12	WET0211	PRESSURE REGULATOR	2
13	UPH1496	REDUCER	1

9.12.13 WST1039 – Tape Shoe Assembly




WST1039 - TAPE SHOE ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0225	SHAFT, 90L	2
2	WET0191	HEX ADAPTER	4
3	WET0161	SLEEVE TUBE	2
4	UPH4613	KNIFE ARM BUMPER 6"TH	2
5	UF6340	SS FW M5	4
6	UF7011	SS BHCS M5-0.8 X 12mm	2
7	WST1050	MAIN ASS'Y	1
8	WET0177	SHAFT, dia 10, 100L	1
9	UF7021	SS LW M5	2
10	UF4319	BHCS M5-0.8 x 8mm	2
11	WST1051	HINGE ASS'Y	1

9.12.14 WST1031 – Water Pot Assembly - Same as for Bottom Tape Head Assembly.

Refer to [9.11.13 WST1031 – Water Pot Assembly](#).

9.12.15 WST1035 – Cover with Handle



WST1035 - COVER WITH HANDLE

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	WET0234	HANDLE	1
2	WET0233	COVER PLATE	1
3	UF7011	SS BHCS M5-0.8 X 12mm	2

www.Intertapepolymer.com

Intertape Polymer Group © 2021